

Assembly Instruction ITEM NO.:

Thank you for purchasing this quality product. Be sure to check all packaging material carefully for small parts that may have come loose inside the carton during shipment. HARDWARE LIST: PARTS LIST: **(**6) NO DESCRIPTION QTY **SKETCH** Bolt 4PCS M8X35 1PCS Top b Long bolt 4PCS M8X620 В Middle board \bigcirc 1PCS \mathbf{c} Long nut 8PCS $022 \times 010 \times 2$ C d **Pedestal** Flat washer 4PCS 1PCS M8X25 е 1PCS Allen key 6# D Baes 1PCS PUT THE MIDDLE BOARD ON THE TOP AND USE THE ALLEN KEY TO STEP 4 FASTEN THE NUTS AND FLAT USE THE ALLEN KEY TO FASTEN WASHERS TO THE BOLTS. THE LONG NUTS AND FLAT WASHERS TO THE BOLTS. STEP 2 FASTEN THE LONG BOLTS AND INSERT WOODEN TENON. STEP 3 PLACE THE PEDESTAL BASE THROUGH THE LONG BOLTS FINISHED MADE IN CHINA