


ASSEMBLY INSTRUCTIONS



TOOLS REQUIRED




Allen Wrench

(Included)



**Phillips
Screwdriver**

(Not Included)



**2 - People
Recommended**

ASSEMBLY RATING



EASY —————> DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.



FOA Intro

Thank you for your purchase!

We hope you enjoy this new addition to your home for many years to come.

Our commitment to providing quality products does not simply end when you purchase our product. We fully stand behind our products from start to finish. Our customer service department is available Monday – Friday 8:30 AM – 5:30 PM Pacific and can help with assembly questions as well as, if necessary, replacing damaged or missing parts. To help expedite our service, please have these assembly instructions readily available, along with your order receipt.



Consumer Hotline
Toll-Free 1-888-980-5122



WEBSITE
www.foagroup.com



Monday to Friday
8:30AM- 5:30PM (PST)



E-MAIL
cs.ec@foagroup.com



foagroup



FurnitureOfAmerica



CHECK BEFORE STARTING

☐

Are you missing anything?

Double-check all parts, hardware and accessories listed on Page 6 are accounted for.

☐

Check out our Quick Tips!

We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!

☐

Should we send any replacements?

Are there any irregularities or flaws in the parts? We can send replacements!


☐

Prep Time!

Please review the assembly instructions and all diagrams prior to assembling. Arrange parts as recommended on Page 7 and group identical hardware together to make assembling easier.



PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.



Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.




Suitable Location

Assembling near the area of the intended location is highly recommended.




Sufficient Space

Make sure you have enough space to move around during the assembly.



Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent scratches.



Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.


ASSEMBLY AND CARE ADVICE



**FAILURE TO FOLLOW THE GUIDELINES BELOW MAY
RESULT IN INJURY AND/OR PROPERTY DAMAGE.**



Position each part correctly
and insert screws or bolts into
their respective holes.



Turn clockwise to tighten and
only tighten when step is
completed or when instructed
to do so.



Use the appropriate hand tools
or power tools for assembly.
Select steps, such as tightening
screws and/or bolts, may require
hand tools to avoid causing
damage during assembly.



Save the instructions and store
any supplied tools for later
maintenance.

After two weeks, check and
tighten any loose hardware and
repeat again every six months
thereafter.


IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

ACCENT CHAIR

CM-AC6265 (VN)




- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.




PARTS

#1 1pc



Chair Back

#2 1pc




Seat Cushion

#3 1pc




Right Arms

#4 1pc



Left Arms

#5 1pc



Cross Bar

HARDWARE

#A 13pcs



Bolt Ø5/16" x 1-3/4"

#B 13pcs




Flat Washer Ø5/16"

#C 13pcs



Lock Washer Ø5/16"

#D 2pcs



Cam Pin Ø8x43mm

#E 2pcs



Barrel Nut Ø15x22mm

#F 2pcs




Bolt Ø8x14mm

#G 4pcs




Wood Dowel Ø10 x 30mm

#H 1pc



Allen Key 5mm

Exploded View




ASSEMBLY INSTRUCTIONS

Align chair back (#1) to seat cushion (#2), then secure by using bolts (#A) with washers (#B,C).

1


Part (#1) x1pc
Part (#2) x1pc
Hardware (#A) x3pcs
Hardware (#B) x3pcs
Hardware (#C) x3pcs



2

Part (#4) x1pc
Hardware (#A) x5pcs
Hardware (#B) x5pcs
Hardware (#C) x5pcs

Align chair (#1,2) to left arm (#4), then secure by using bolts (#A) with washers (#B,C).




ASSEMBLY INSTRUCTIONS

Attach dowels (#G) and cam pins (#D) to the holes of the left arms (#4). Align cross bar (#5) to the left arm (#4), then secure by using barrel nut (#E) with bolt (#F).

3


- Part #5 x1pc
- Hardware #D x1pc
- Hardware #E x1pc
- Hardware #F x1pc
- Hardware #G x2pcs



4

- Part #3 x1pc
- Hardware #A x5pcs
- Hardware #B x5pcs
- Hardware #C x5pcs
- Hardware #D x1pc
- Hardware #E x1pc
- Hardware #F x1pc
- Hardware #G x2pcs

Attach dowels (#G) and cam pins (#D) to the holes of the right arms (#3). Align cross bar (#5) to the right arm (#3), then secure by using barrel nut (#E) with bolt (#F).



Align chair (#1,2) to right arm (#3), then secure by using bolts (#A) with washers (#B,C).

ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.



Keep this handy!

Please retain this instruction manual and any order-related information for future reference.



Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting or adjusting the placement.