

#### MODEL#

### CM3156PT

### Questions?

GIVE US A CALL: 1-888-980-5122 MON-FRI 8:30AM - 5:30PM (PT)

### **TOOLS REQUIRED**



#### Allen Wrench

(Included)



### Phillips Screwdriver

(Not Included)



2 - People Recommended

### **ASSEMBLY RATING**



EASY — DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.

VERSION # 21-11-23





### Thank you for your purchase!

We hope you enjoy this new addition to your home for many years to come.

Our commitment to providing quality products does not simply end when you purchase our product. We fully stand behind our products from start to finish. Our customer service department is available Monday – Friday 8:30 AM – 5:30 PM Pacific Time and can help with assembly questions as well as, if necessary, replacing damaged or missing parts. To help expedite our service, please have these assembly instructions readily available, along with your order receipt.



Consumer Hotline Toll-Free 1-888-980-5122



WEBSITE www.foagroup.com











Monday to Friday 8:30AM- 5:30PM (PT)



E-MAIL cs.ec@foagroup.com



FurnitureOfAmerica



	Are you missing anything?  Double-check all parts, hardware and	Check out our Quick Tips! We recommend reviewing the pre-assembly
	accessories listed are all acccounted for.	 handouts. Even experts need a refresher now and then!
	Should we send any replacements?	Prep Time!
	Are there any irregularities or flaws in the parts? We can send replacements!	Please review the assembly instructions and all diagrams prior to assembling.

# PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.





#### **Teamwork**

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.





### **Suitable Location**

Assembling near the area of the intended location is highly recommended.





### **Sufficient Space**

Make sure you have enough space to move around during the assembly.





### **Avoid Scratches**

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.





#### **Flat Surface**

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

# ASSEMBLY AND CARE ADVICE




FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.




Position each part correctly and insert screws or bolts into their respective holes.




Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Save the instructions and store any supplied tools for later maintenance.



After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

# **TABLE**

### CM3156PT



- · Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.



### **PARTS**





1pc



#3) 1pc



Table Top







Table Leg





and back panel



1pc



1pc



1pc

Table Leg

Table Leg



1pc

1pc



**(**#10) 1pc



**Short Stretcher** 



1) 1pc

Long Stretcher




**(**#12**)** 1pc



Top Panel
















Left Shelf Panel

Panel

### **HARDWARE**



8pcs



8pcs



8pcs



10pcs






(0) (0)

Ø5/16" x 2-3/8"


Ø5/16" x 11mm


Ø5/16" x 19mm


Ø1/4" x 1-3/16"



### Allen Key M4








Part #1)x 1pc
Part #4)x 1pc
Part #5)x 1pc
Hardware #A x 4pcs
Hardware #B x 4pcs


Hardware #Ox 4pcs



4


Part #4x 1pc Part #5x 1pc

Hardware #Dx 4pcs
Hardware #Fx 4pcs



6

Part #6x 1pc
Hardware #Ax 2pcs
Hardware #Bx 2pcs
Hardware #Cx 2pcs



### 7

Part #7x 1pc


Part #8x 1pc

Hardware #Ex 1pc

Hardware #Fx 1pc

Hardware #G x 1pc

Hardware (L) x 1pc



# 8


Part #3x 1pc


Hardware (#A)x 2pcs

Hardware (#B) x 2pcs


Hardware (#C) x 2pcs


Hardware (#I)x 2pcs





10 Part #14x 4pcs





# ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.

✓ Keep this handy!

Please retain this instruction manual and any order-related information for future reference.

✓ Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting of adjusting the placement.