


Furniture of America[®]

Assembly Instructions

For more information contact our team: service.ec@foagroup.com

CM3394T





ASSEMBLY RATING

The Assembly Rating is a 5-point system that shows the degree of effort needed in assembling a specific product (with 1 being easy and 5 being difficult). For some products, two persons are recommended.

EASY  DIFFICULT

Tools Required For Assembly:

Allen Wrench




2 PERSONS RECOMMENDED


ASSEMBLY & CARE ADVICE

FOR YOUR FURNITURE TO LAST, CORRECT ASSEMBLY AND PROPER MAINTENANCE ARE NECESSARY. PLEASE FOLLOW THE INFORMATION PROVIDED BELOW TO FULLY ENJOY YOUR FURNITURE.


BASIC ASSEMBLY TECHNIQUES




When lock or spring washer is used in an assembly, please make sure the lock or spring washer is placed between the larger flat washer and the head of the screw or bolt.




Position each part correctly and insert screws or bolts into their respective holes by hand tighten or using the proper hand tool. Only tighten when step is completed or when instructed to do so.




Use cardboard or carpet area when assembling furniture to prevent scratches. Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.



Some furniture comes with height adjustment knobs underneath each leg. To lower or to raise each leg, you need to turn clockwise or counterclockwise, respectively.




Make sure all parts are properly aligned, then use the appropriate hand tool to completely tighten the bolts or screws. Do not use power tools and do not overtighten.




Save the instructions and store the Allen wrench or any supplied tool for later maintenance. After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.



FAILURE TO FOLLOW THE GUIDELINES ABOVE MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Before you begin, please read Page 2 of "Assembly and Care Advice".

And remember, do not tighten until each step is completed or instructed.

Parts List


Hardware List



#1 x 1pc
Table Top



#A x 28pcs
Bolt Ø5/16"X1-1/2"



#2 x 1pc
Table Top Base




#B x 28pcs
Lock Washer



#3 x 2pcs
Right Panel




#C x 28pcs
Flat Washer



#4 x 2pcs
Left Panel




#D x 1pc
Allen Wrench



#5 x 2pcs
Side Panel



#6 x 2pcs
Glass




#7 x 1pc
Base



Align right and left panels (#3,4) to the holes of the side panels (#5), then secure by using bolts (#A) with washers (#B,C).


#A x 12pcs
#B x 12pcs
#C x 12pcs



X 2




#A x 3pcs
#B x 3pcs
#C x 3pcs



Align base (#7) to the holes of the panels (#3,4,5), then secure by using bolts (#A) with washers (#B,C).




Slide glass (#6) to connect to both sided panels (#3,4).



Secure panels (#3,4,5) to the base (#7) by using bolts (#A) with washers (#B,C).


#A x 3pcs
#B x 3pcs
#C x 3pcs







#5

#A x 6pcs
#B x 6pcs
#C x 6pcs




#2

Align table top base (#2) to the holes of the base, then pull out the electrical connectors through the table top base (#2). Secure table top base (#2) to the base by using bolts (#A) with washers (#B,C).




#6

#A x 4pcs
#B x 4pcs
#C x 4pcs








#1





Align table top base to the holes of the table top (#1), then secure by bolts (#A) with washers (#B,C). Make sure all 4 electrical connectors are extended outwards.



2) Open battery case, then insert batteries into the designated slots. Make sure the battery case is turned off before doing this process.



1) Align and connect the electrical connectors together with the electrical connectors of the table top.



Turn the battery case on, then touch the "touch me" sticker to light up.