

ASSEMBLY INSTRUCTIONS

MODEL#

CM3476T-7PK

Questions?

GIVE US CALL: 1-888-980-5122 MON-FRI 8:30AM - 5:30PM (PST)

TOOLS REQUIRED



Allen Wrench

(Included)



Phillips Screwdriver

(Not Included)



2 - People Recommended

ASSEMBLY RATING



EASY ----- DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.



VERSION # 20-07-14





Thank you for your purchase!

We hope you enjoy this new addition to your home for many years to come.

Our commitment to providing quality products does not simply end when you purchase our product. We fully stand behind our products from start to finish. Our customer service department is available Monday – Friday 8:30 AM – 5:30 PM Pacific and can help with assembly questions as well as, if necessary, replacing damaged or missing parts. To help expedite our service, please have these assembly instructions readily available, along with your order receipt.



Consumer Hotline Toll-Free 1-888-980-5122



WEBSITE www.foagroup.com











Monday to Friday 8:30AM- 5:30PM (PST)



E-MAIL cs.ec@foagroup.com



FurnitureOfAmerica



	Are you missing anything?	Check out our Quick Tips!
	Double-check all parts, hardware and accessories listed on Page 6 are accounted for.	We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!
	Should we send any replacements?	Prep Time!
	Are there any irregularities or flaws in the parts? We can send replacements!	Please review the assembly instructions and all diagrams prior to assembling. Arrange parts as recommended on Page 7 and group identical hardware together to make assembling easier.

PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.





Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.





Suitable Location

Assembling near the area of the intended location is highly recommended.





Sufficient Space

Make sure you have enough space to move around during the assembly.





Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent scratches.





Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE




FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.




Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Save the instructions and store any supplied tools for later maintenance.



After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

TABLE SET

CM3476T-7PK



- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.



PARTS






Table Top





Table Leg





Chair Back





Seat



Front Leg

HARDWARE





Bolt Ø5/16"x 2-3/8"



Bolt Ø1/4"x 1-1/2"





Lock Washer Ø5/16" x 12mm





Bolt Ø1/4"x 2-3/8"





Flat Washer Ø5/16" x 19mm





Lock Washer Ø1/4" x 11mm





Bolt Ø1/4"x 3"




Flat Washer Ø1/4" x 19mm





Allen Wrench 4mm

Exploded View



ASSEMBLY INSTRUCTIONS


1

Part #1)x 1pc
Part #2x 4pcs
Hardware #A)x 8pcs

Hardware #Bx 8pcs

Hardware #Ox 8pcs

Align table legs (#2) to the table top (#1), then secure by using bolts (#A) with washers (#B,C).




2

Part #4x 6pcs

Part #5x 12pcs

Hardware #Fx 24pcs Hardware #Gx 24pcs Hardware #Hx 24pcs

Align front chair legs (#5) to the seat (#4), then secure by using bolts (#F) with washers (#G,H).




ASSEMBLY INSTRUCTIONS

3

Part #3 x 6pcs Hardware #E x 12pcs Hardware #G x 12pcs


Align seat (#4) to the chair back (#3), then secure by using bolts (#E) with washers (#G,H).



4

Hardware #Dx 24pcs Hardware #Gx 24pcs Hardware #Hx 24pcs

Secure seat (#4) onto chair back (#3) by using bolts (#D) with washers (#G,H).



ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.

✓ Keep this handy!

Please retain this instruction manual and any order-related information for future reference.

✓ Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting of adjusting the placement.