


Assembly Instructions

For more information contact our team: service.ec@foagroup.com

CM7075BN



ASSEMBLY RATING

The Assembly Rating is a 5-point system that shows the degree of effort needed in assembling a specific product (with 1 being easy and 5 being difficult). For some products, two persons are recommended.


EASY



DIFFICULT

Tools Required For Assembly:

Allen Wrench




(Included)

Phillips Screwdriver



(Not Included)




2 PERSONS RECOMMENDED


ASSEMBLY & CARE ADVICE

FOR YOUR FURNITURE TO LAST, CORRECT ASSEMBLY AND PROPER MAINTENANCE ARE NECESSARY. PLEASE FOLLOW THE INFORMATION PROVIDED BELOW TO FULLY ENJOY YOUR FURNITURE.


BASIC ASSEMBLY TECHNIQUES




When lock or spring washer is used in an assembly, please make sure the lock or spring washer is placed between the larger flat washer and the head of the screw or bolt.




Position each part correctly and insert screws or bolts into their respective holes by hand tighten or using the proper hand tool. Only tighten when step is completed or when instructed to do so.




Use cardboard or carpet area when assembling furniture to prevent scratches. Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor. No dragging of products/parts.



Some furniture comes with height adjustment knobs underneath each leg. To lower or to raise each leg, you need to turn clockwise or counterclockwise, respectively.




Make sure all parts are properly aligned, then use the appropriate hand tool to completely tighten the bolts or screws. Do not use power tools and do not overtighten.




Save the instructions and store the Allen wrench or any supplied tool for later maintenance. After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.




FAILURE TO FOLLOW THE GUIDELINES ABOVE MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.




Before you begin, please read Page 2 of "Assembly and Care Advice".

And remember, do not tighten until each step is completed or instructed.


Parts List




#1 x 1pc
Bench Cushion




#2 x 2pcs
Side Frame




#3 x 1pc
Front Frame



#4 x 1pc
Back Frame



#5 x 2pcs
Vertical Panel



#6 x 3pcs
Bottom Panel



#7 x 4pcs
Leg

Hardware List



#A x 16pcs
Bolt 1/4" x 1/2"



#B x 4pcs
Bolt 1/4" x 2"




#C x 2pcs
Bolt 1/4" x 2"



#D x 8pcs
Bolt M5x10




#E x 12pcs
Screw M5x12



#F x 1pc
Allen Wrench M4





Exploded View



Align side frames (#2) to the front and back frames (#3,4), then secure by using bolts (#A).

#A x 8pcs







#3

#E x 12pcs

Align bottom panels (#6) to the bottom tabs from the inside of the unit, then secure by using screws (#E).





SCREWDRIVER
(NOT PROVIDED)



#4

#A x 8pcs





Align legs (#7) to the bottom of the unit, then secure by using bolts (#A).



#5

#D x 8pcs

Slide vertical panels (#5) to the inside holes of the unit, then secure by using bolts (#D).




SCREWDRIVER
(NOT PROVIDED)



#6

#B x 4pcs
#C x 2pcs



Align seat cushion (#1) to the unit, then secure by using bolts (#B,C) as shown in the diagram.

