

ASSEMBLY INSTRUCTIONS

MODEL

FOA7490D-M

Questions?

GIVE US A CALL: 1-888-980-5122 MON – FRI 8:30AM – 5:30PM (PT)

TOOLS REQUIRED



Allen Wrench

(Included)




2 - People Recommended

ASSEMBLY RATING



EASY → DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.



VERSION # 21-04-26





Thank you for your purchase!

We hope you enjoy this new addition to your home for many years to come.

Our commitment to providing quality products does not simply end when you purchase our product. We fully stand behind our products from start to finish. Our customer service department is available Monday - Friday 8:30 AM- 5:30 PM Pacific Time and can help with assembly questions as well as, if necessary, replacing damaged or missing parts. To help expedite our service, please have these assembly instruction readily available, along with your order receipt.



Are you missing anything? Double-check all parts, hardware and		Check out our Quick Tips! We recommend reviewing the pre-assembly	
accessories listed on Page 6 are accounted for.		handouts. Even experts need a refresher now and then!	
Should we send any replacements?		Prep Time!	
Are there any irregularities or flaws in the parts? We can send replacements!		Please review the assembly instructions and all diagrams prior to assembling.	

PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.





Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.





Suitable Location

Assembling near the area of the intended location is highly recommended.





Sufficient Space

Make sure you have enough space to move around during the assembly.





Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent scratches.





Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE




FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.



Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Save the instructions and store any supplied tools for later maintenance.



After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.


IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

DRESSER & MIRROR

FOA7490D-M



- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.



PARTS



1pc



Dresser



1pc



Mirror



2pcs



Support Rail

HARDWARE



2pcs



Screw 1/3" x 2"



8pcs



Lock Washer



2pcs



Fischer





Flat Washer





Bolt 1/4" x 1.8"




1pc



Allen Wrench


Exploded View



FOA7490D-M is packed in 2 caces

Carton	Disignation		Part	Hardware
FOA7490D	Dresser	#1		
	Mirror	#2		() #A 2pcs #B 2pcs
FOA7490M	Mirror Support	#3		#C 8pcs #D 8pcs
			2pcs	#E 8pcs #F 1pc

ASSEMBLY INSTRUCTIONS



ASSEMBLY INSTRUCTIONS

Option-2 Is with support rails (#3).

3

Part #1 x1pc Part #2 x1pc


Part #3 x2pcs

Hardware #O x 8pcs

Hardware#D x 8pcs


Hardware #E) x 8pcs

Hardware #F) x 1pc



Align support rails (#3) to the mirror (#2) and dresser (#1), then secure by using bolts (#C) with washers (#D,E).

4



ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.

Keep this handy!

Please retain this instruction manual and any order-related information for future reference.

✓ Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting of adjusting the placement.