

ASSEMBLY INSTRUCTION


MODEL: MVP-BLANCHE BLK-P2 R

DESCRIPTION: POWER RECLINER WITH POWER HEADREST, 2 ARM COOLERS, ACRYLIC BOARD, BEHIND EAR STORAGE AND IMMERSE SOUND SPEAKER WITH LED

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment

Bluetooth Connection: Enable Bluetooth on your device and pair with [GFUSA] from the list of available devices.

PARTS LIST:			
NO.	DESCRIPTION	SKETCH	Q'TY
A	Seat		1 PC
B	Backrest		1 PC
C	Left Wing		1 PC
D	Right Wing		1 PC



ASSEMBLY INSTRUCTION


MODEL: MVP-BLANCHE BLK-P2 R

DESCRIPTION: POWER RECLINER WITH POWER HEADREST, 2 ARM COOLERS, ACRYLIC BOARD, BEHIND EAR STORAGE AND IMMERSE SOUND SPEAKER WITH LED

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment


Step 1:

Attach the Backrest (B) to the Seat (A).




Step 2:

Attach the Wings (C/D) to the Left/Right side of the Backrest (B).



Step 3:



ASSEMBLY INSTRUCTION

MODEL: MVP-BLANCHE BLK-P2 R

DESCRIPTION: POWER RECLINER WITH POWER HEADREST, 2 ARM COOLERS, ACRYLIC BOARD, BEHIND EAR STORAGE AND IMMERSE SOUND SPEAKER WITH LED

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment


Step 4:

Setting Up

Please read the following instructions carefully to install your new wine cooler properly and safely.


1. Let the wine cooler run empty for about 1 hour before storing any wine bottles inside.
2. This unit runs at its default temperature of 47°F / 8°C. You can adjust the cooler's internal temperature by using the smart temperature controls on the LED display.
 - a. Press  to increase your cooler's internal temperature.
 - b. Press  to decrease your cooler's internal temperature.
 - c. This unit has a temperature range between 47° - 65°F, or 8-18°C.
3. Press  to turn the interior blue LED light ON. Press the button again to turn it OFF.

NOTE ON COOLING: This cooling unit's actual internal temperature depends on the ambient temperature. While you can set the cooler's temperature within its operating range, its internal temperature may not reach the selected temperature if the surrounding temperature is too high.



Step 5:

Open the footrest or move the headrest by pressing the power button on/off.



- ① Led Light On/Off
- ② Type C
- ③ USB PORT
- ④ Open/Close recliner
- ⑤ Open/Close headrest
- ⑥ Home

