





Assembly Instruction

Model: LW 2385


Description: KING BED

Thank you for your support of our product. Be sure to check all packing material carefully for small parts that might have come loose during shipment.

Part List					Part List			
No.	Description	Sketch	Size	Qty.	No.	Description	Sketch	Qty.
1	Bolt		M8 x 100mm	4 PCS	A	Headboard		1 Pc
2	Lock Washer		M8	4 PCS	B	Footboard		1 Pc
3	Bolt + (Lock & Flat Washer)		M8 x 45mm	10 PCS	C	Side Rail (Left & Right)		2 Pcs
4	Bolt + (Lock & Flat Washer)		M8 x 25mm	12 PCS	D	Headboard Support		2 Pcs
5	Allen Key		M5	1 PC	E	Headboard Legs (Left & Right)		2 Pcs
6	Screws		M4 x 32mm	16 PCS	F	Footboard Legs		2 Pcs
7	Phillips head screwdriver		No Included		G	Slats		14 Pcs
					H	Support Legs		6 Pcs
					I	Center Wood Support		2 Pcs
					J	Adapter (Lamp + Wireless Charging + Speaker)		1 Pc


Step 1

1.1 - ASSEMBLY HEADBOARD (A) WITH HEADBOARD LEGS (E) (LEFT & RIGHT) BY USING BOLT (3) & ALLEN KEY (5).




Step 2

2.1 - ASSEMBLY HEADBOARD (A) AND HEADBOARD LEGS (E) (LEFT & RIGHT) WITH HEADBOARD SUPPORT (D) BY USING BOLT (3) & ALLEN KEY (5).



Step 3

3.1 ASSEMBLY FOOTBOARD LEGS (F) WITH FOOTBOARD (B) BY USING BOLT (1), LOCK WASHER (2) & ALLEN KEY (5).



Assembly Instruction


Model: LW 2385

Description: KING BED

STEP 4


4.1 ASSEMBLY SIDE RAIL (C) (LEFT & RIGHT) WITH HEADBOARD LEGS (E) (LEFT & RIGHT) BY USING BOLT (4) & ALLEN KEY (5).

4.2 ASSEMBLY SIDE RAIL (C) (LEFT & RIGHT) WITH FOOTBOARD (B) BY USING BOLT (4) & ALLEN KEY (5).




STEP 5

5.1 ATTACH SUPPORT LEGS (H) TO CENTER WOOD SUPPORT (I).



STEP 6


6.1 SECURE SLATS (G) WITH SCREW (6) BY PHILLIPS HEAD SCREWDRIVER (7) (no included).



BACK VIEW

STEP 7

7.1 PLUG IN ADAPTER (LAMP + WIRELESS CHARGING + SPEAKER) (J) WITH CABLE.




Assembly Instruction


Model: LW 2385

Description: KING BED

Headboard Function




Lamp #1




#1 You can adjust the brightness according to your needs. Turn on the light by touching it, and the brightness has two levels. The third touch will turn off the light.

Speaker #2





#2 After turning on the Bluetooth on your phone, locate the name 'eMoMo Remo 4' in the Bluetooth settings, then click and confirm to establish the connection. This ensures that the speaker can be successfully connected.



Wireless Charger #3

#3 If your phone supports wireless charging, you can directly place it on the wireless charging pad. If your phone doesn't support wireless charging, you can use a charging cable for charging. There are two wired interfaces available, and you can rotate to find the interface you need for charging.



FINISHED

