

ASSEMBLY INSTRUCTION

Model:U5915-PCRLSW/SUBSPKR-MULTI-CLRLD

Description: POWER CONSOLE RECLINING LOVESEAT WITH SPEAKERS WITH SUBWOOFER AND MULTI-COLOR LED


Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment

Bluetooth Connection: Enable Bluetooth on your device and pair with [GFUSA] from the list of available devices.

PARTS LIST:


NO.	DESCRIPTION	SKETCH	Q'TY
A	Seat Body		1 PC
B	Left Backrest		1 PC
C1	Console Backrest		1 PC
C2	Console Backrest		1 PC
D	Right Backrest		1 PC

PARTS LIST:

NO.	DESCRIPTION	SKETCH	Q'TY
E	Left wing		1 PC
F	Right wing		1 PC
G	Adaptor		1 PC
H	Adaptor speakers		1 PC


Step 1:

Take the Console Backrest (C1/C2) and Wings (E/F) out of the Seat Base part of the Seat (A).




Step 2:

Attach the Console Backrest (C1/C2) by Close the zipper.




Step 3:

Attach Backrest (B/C/D) to the Seat (A).



Step 4:

Attach the Left/Right Wings (C/D) to the Left/Right side of the Backrest (B/D).



ASSEMBLY INSTRUCTION


Model: Model:U5915-PCRLSW/SUBSPKR-MULTI-CLRLED

Description: POWER CONSOLE RECLINING LOVESEAT WITH SPEAKERS WITH SUBWOOFER AND MULTI-COLOR LED

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment


Step 5:

Important: Connect the power wire under the Armrest frame to the power source through out The Adaptor(G/H).



Step 6:

Important: Open the Footrest by pressing the power button on/off.



Operation Instructions

1. Upon powering on, the product automatically starts. The light strip runs through a colorful cycle and then lights up blue.
2. The control button blinks blue, and a voice prompt says "Power On." At this point, the product enters Bluetooth pairing mode, and the voice prompt says "Wait for Preparing."
3. If Bluetooth fails to connect, the control button blinks blue rapidly, and the product automatically enters broadcast search mode. The Bluetooth search lasts for 10 seconds, followed by 5 seconds of broadcast search, and continues to cycle.
4. Open the Bluetooth function on your phone, search for the Bluetooth name "E309T_PRO," and pair it. Once paired successfully, the voice prompt says "Bluetooth Connected," and the control button blinks blue rapidly, continuing the broadcast search.
5. Open the music player on your phone and start playing a song. The speaker will automatically respond and play the music. The light strip will default to the colorful cycle and will move with the rhythm of the music. The subwoofer will also vibrate in sync with the music's rhythm. When the music pauses, the light strip lights up blue, and the subwoofer stops vibrating.
6. You can control the music on your phone, including previous track, next track, pause/play, volume down, and volume up.
7. Press the control button briefly to turn off the device, and the voice prompt will say "Power Off." Press the control button again briefly to turn the device on.