

ASSEMBLY INSTRUCTION

DESCRIPTION : POWER RECLINER WITH POWER HEADREST,
ARM STORAGE, IMMERSE SPEAKER WITH ALL AROUND SOUND
REACTIVE LED AND VIBRATION

MODEL: U1895-P2 R

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment


Bluetooth Connection: Enable Bluetooth on your device and pair with [eMoTion Sterling CY115] from the list of available devices.

PARTS LIST:

NO.	DESCRIPTION	SKETCH	Q'TY
A	Seat Body		1 PC
B	Backrest		1 PC
C	Power source		2 PCS


Step 1:

Attach Backrest (B) to the Seat (A).




Step 2:

Connect the power wire under the Armrest frame to the Power source (C).




Step 3:



Step 4:

Open the footrest by pressing the power button on/off.



ASSEMBLY INSTRUCTION

DESCRIPTION : POWER CONSOLE RECLINING LOVESEAT
WITH POWER HEADREST, ARM STORAGE, IMMERSE SPEAKER
WITH ALL AROUND SOUND REACTIVE LED AND VIBRATION

MODEL: U1895-P2 CRLS

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment

Bluetooth Connection: Enable Bluetooth on your device and pair with [eMoTion Sterling CY115] from the list of available devices.

PARTS LIST:


NO.	DESCRIPTION	SKETCH	Q'TY
A	Seat Body		1 PC
B	Left Backrest		1 PC
C	Console Backrest		1 PC
D	Right Backrest		1 PC

PARTS LIST:

NO.	DESCRIPTION	SKETCH	Q'TY
E	Power source		1 PC
F	Power source		1 PC
G	Male bracket		2 PCS


Step 1:

Attach Backrest (B/D) to the Seat (A).




Step 2:

Slide male bracket (G) into the bottom of seat (A).




Step 3:



Step 4:

Connect the power wire under the Armrest frame to the Power source (E/F).




ASSEMBLY INSTRUCTION

DESCRIPTION : POWER CONSOLE RECLINING LOVESEAT
WITH POWER HEADREST, ARM STORAGE, IMMERSE SPEAKER
WITH ALL AROUND SOUND REACTIVE LED AND VIBRATION

MODEL: U1895-P2 CRLS


Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment

Step 5:



Step 6:

Open the footrest by pressing the power button on/off.



ASSEMBLY INSTRUCTION

DESCRIPTION : POWER RECLINING SOFA WITH POWER HEADREST,
ARM STORAGE, IMMERSE SPEAKER WITH ALL AROUND SOUND
REACTIVE LED AND VIBRATION

MODEL: U1895-P2 RS

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment

Bluetooth Connection: Enable Bluetooth on your device and pair with [eMoTion Sterling CY115] from the list of available devices.

PARTS LIST:


NO.	DESCRIPTION	SKETCH	Q'TY
A	Seat Body		1 PC
B	Left Backrest		1 PC
C	Middle Backrest		1 PC

PARTS LIST:

NO.	DESCRIPTION	SKETCH	Q'TY
D	Right Backrest		1 PC
E	Power source		2 PCS


Step 1:

Attach Backrest (B/C/D) to the Seat (A).




Step 2:

Connect the power wire under the Armrest frame to the Power source (E).



Step 3:



Step 4:

Open the Footrest by pressing the power button on/off.

