

ASSEMBLY INSTRUCTION

DESCRIPTION : POWER RECLINING SOFA WITH POWER HEADREST,
ARM STORAGE, IMMERSE SPEAKER WITH ALL AROUND SOUND
REACTIVE LED AND VIBRATION

MODEL: U1895-P2 RS

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment

Bluetooth Connection: Enable Bluetooth on your device and pair with [eMoTion Sterling CY115] from the list of available devices.

PARTS LIST:


NO.	DESCRIPTION	SKETCH	Q'TY
A	Seat Body		1 PC
B	Left Backrest		1 PC
C	Middle Backrest		1 PC

PARTS LIST:

NO.	DESCRIPTION	SKETCH	Q'TY
D	Right Backrest		1 PC
E	Power source		2 PCS


Step 1:

Attach Backrest (B/C/D) to the Seat (A).




Step 2:

Connect the power wire under the Armrest frame to the Power source (E).



Step 3:



Step 4:

Open the Footrest by pressing the power button on/off.

