

ASSEMBLY INSTRUCTION

Model: U8879-PRS-W/LED-GL-SS

Description: POWER RECLINING
SOFA W LED & AUDIO SUBWOOFER

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment

Bluetooth Connection: Enable Bluetooth on your device and pair with [GFUSA] from the list of available devices.

PARTS LIST:


NO.	DESCRIPTION	SKETCH	Q'TY
A	Seat Body		1 PC
B	Left Backrest		1 PC
C	Middle Backrest		1 PC
D	Right Backrest		1 PC
E	Left wing		1 PC

PARTS LIST:

NO.	DESCRIPTION	SKETCH	Q'TY
F	Right wing		1 PC
G	Power source		1 PC
H	Power source for led and subwoofer		1 PC


Step 1:

Attach Backrest (B/C/D) to the Seat (A).




Step 2:

Attach the Left/Right Wings (E/F) to the Left/Right side of the Backrest (B/D).




Step 3:

Connect the power wire under the Armrest frame to the Power source (G/H).



Step 4:

Open the Footrest by pressing the power button on/off.



Made in Vietnam