

ASSEMBLY INSTRUCTION

MODEL : U8880-PR

DESCRIPTION : POWER RECLINER WITH ARMREST CUPHOLDER


Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment

PARTS LIST:

NO.	DESCRIPTION	SKETCH	Q'TY
A	Seat Body		1 PC
B	Backrest		1 PC
C	Left wing		1 PC
D	Right wing		1 PC
E	Power source		1 PC


Step 1:

Attach Backrest (B) to the Seat (A).




Step 2:

Attach the Left/Right Wings (C/D) to the Left/Right side of the Backrest (B).




Step 3:

Connect the power wire under the Armrest frame to the Power source (E).



Step 4:

Open the footrest by pressing the power button on/off.



ASSEMBLY INSTRUCTION

DESCRIPTION: POWER CONSOLE RECLINING LOVESEAT
WITH ARMREST CUPHOLDER, CONSOLE COOLER W/ WC &
WATCH CHARGER, IMMERSE SOUND AND MULTI-COLOR LED

MODEL: U8881-PCRLS-IMMERSE

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment

Bluetooth Connection: Enable Bluetooth on your device and pair with [GFUSA] from the list of available devices.

PARTS LIST:


NO.	DESCRIPTION	SKETCH	Q'TY
A	Seat Body		1 PC
B	Left Backrest		1 PC
C	Console Backrest		1 PC
D	Right Backrest		1 PC
E	Left wing		1 PC

PARTS LIST:

NO.	DESCRIPTION	SKETCH	Q'TY
F	Right wing		1 PC
G	Power source		1 PC
H	Power source (4.5A 90W)		1 PC
I	Power source (3.0A 87W)		1 PC


Step 1:

Attach Backrest (B/C/D) to the Seat (A).




Step 2:

Attach the Left/Right Wings (E/F) to the Left/Right side of the Backrest (B/D).



Step 3:

Connect the power wire under the Armrest frame to the Power source (G/H/I).




ASSEMBLY INSTRUCTION

DESCRIPTION: POWER CONSOLE RECLINING LOVESEAT
WITH ARMREST CUPHOLDER, CONSOLE COOLER W/ WC &
WATCH CHARGER, IMMERSE SOUND AND MULTI-COLOR LED


MODEL: U8881-PCRLS-IMMERSE

Step 4 :



Step 5 :

Open the Footrest by pressing the power button on/off.



ASSEMBLY INSTRUCTION

DESCRIPTION: POWER RECLINING SOFA WITH ARMREST
CUPHOLDER, DDT WITH WATCH CHARGER, IMMERSE
SPEAKER WITH SUBWOOFER AND MULTI-COLOR LED

MODEL: U8881-PRS-IMMERSE

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment

Bluetooth Connection: Enable Bluetooth on your device and pair with [GFUSA] from the list of available devices.

PARTS LIST:


NO.	DESCRIPTION	SKETCH	Q'TY
A	Seat Body		1 PC
B	Left Backrest		1 PC
C	Middle Backrest		1 PC
D	Right Backrest		1 PC

PARTS LIST:

NO.	DESCRIPTION	SKETCH	Q'TY
E	Left wing		1 PC
F	Right wing		1 PC
G	Power source		1 PC
H	Power source		1 PC


Step 1:

Attach Backrest (B/C/D) to the Seat (A).




Step 2:

Attach the Left/Right Wings (E/F) to the Left/Right side of the Backrest (B/D).



Step 3:

Connect the power wire under the Armrest frame to the Power source (G).




ASSEMBLY INSTRUCTION

DESCRIPTION: POWER RECLINING SOFA WITH ARMREST
CUPHOLDER, DDT WITH WATCH CHARGER, IMMERSE
SPEAKER WITH SUBWOOFER AND MULTI-COLOR LED

MODEL: U8881-PRS-IMMERSE

Step 4 :



Step 5 :

Open the Footrest by pressing the power button on/off.

