HOOKER®
FURNITURE

# ASSEMBLY INSTRUCTION

ITEM: 6700-75200B-98 Trestle Dining Table Base
6700-75200T-80 Trestle Dining Table Top

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.
Read all instruction and study the drawing carefully before starting the assembly process.


HARDWARE PACK

| NO. | DRAWING | DESCRIPTION | SIZE | Q'TY |
|---|---|---|---|---|
| A | | Allen Wrench | 108*76*5mm | 1PC |
| B | | Bolt | $\frac{5}{16}$"*35mm | 10PCS |
| C | | Lock Washer | $\frac{5}{16}$" | 14PCS |
| D | | Flat Washer | $\frac{5}{16}$" | 14PCS |
| E | | Bolt | $\frac{5}{16}$"*100mm | 4PCS |
| F | | Wood Cap | 52*52*27mm | 4PCS |

PART LIST

| NO. | DRAWING | DESCRIPTION | Q'TY |
|---|---|---|---|
| ① | | Base | 2PCS |
| ② | | Stretcher | 1PC |
| ③ | | Top | 1PC |
| ④ | | Leaf | 2PCS |

## Diagram 1




Step 1 : Attach stretcher (2) between the two bases (1), then use the wood caps (F) to cover the bolts (E).

HOOKER®
FURNITURE

# ASSEMBLY INSTRUCTION

ITEM: 6700-75200B-98 Trestle Dining Table Base
6700-75200T-80 Trestle Dining Table Top

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.
Read all instruction and study the drawing carefully before starting the assembly process.





Diagram 2

Step 2: Attach the base to the top (3).




Diagram 3

Step 3

Adjust Leveler if needed to level table on uneven floor.

HOOKER®
FURNITURE

# ASSEMBLY INSTRUCTION

ITEM: 6700-75200B-98 Trestle Dining Table Base
6700-75200T-80 Trestle Dining Table Top

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.
Read all instruction and study the drawing carefully before starting the assembly process.

Diagram 4





Diagram 5

**Instruction for table leaves:**

1. There are latches at the bottom of table top, unlock the latches as shown in Diagram 4 above.

2. Pull out table top as the arrow direction shown in Diagram 5.

3. Place table leaves (4) between table tops and push table tops together.

4. Lock the latches. (See Diagram 4)

5. Take opposite actions to remove table leaves.

HOOKER®
FURNITURE

# ASSEMBLY INSTRUCTION

ITEM: 6700-75203B-97 Round Dining Table Base
6700-75203T-80 Round Dining Table Top


Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.
Read all instruction and study the drawing carefully before starting the assembly process.

HARDWARE PACK

| NO. | DRAWING | DESCRIPTION | SIZE | Q'TY |
|---|---|---|---|---|
| A |  | Allen Wrench | 5mm | 1PC |
| B |  | Bolt | $\frac{5}{16}$" | 4PCS |
| C |  | Lock Washer | $\frac{5}{16}$" | 4PCS |
| D |  | Flat Washer | $\frac{5}{16}$" | 4PCS |

PART LIST

| NO. | DRAWING | DESCRIPTION | Q'TY |
|---|---|---|---|
| ① |  | Base | 1PC |
| ② |  | Top | 1PC |





STEP 1

HOOKER®
FURNITURE

# ASSEMBLY INSTRUCTION

ITEM: 6700-75203B-97 Round Dining Table Base
6700-75203T-80 Round Dining Table Top

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.
Read all instruction and study the drawing carefully before starting the assembly process.



Adjust Leveler if needed to level table on uneven floor.

STEP 2

HOOKER® FURNITURE

# ASSEMBLY INSTRUCTION

## ITEM: 6700-75207-80 Leg Table w/1-24 in leaf

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.
Read all instruction and study the drawing carefully before starting the assembly process.


PART LIST

| NO. | DRAWING | DESCRIPTION | SIZE | Q'TY |
|---|---|---|---|---|
| A |  | Allen Wrench | 5mm | 1PC |
| B |  | Bolt | $\frac{5}{16}$" | 8PCS |
| C |  | Lock Washer | $\frac{5}{16}$" | 8PCS |
| D |  | Flat Washer | $\frac{5}{16}$" | 8PCS |

PART LIST

| NO. | DRAWING | DESCRIPTION | Q'TY |
|---|---|---|---|
| ① |  | Leg | 4PCS |
| ② |  | Top | 1PC |
| ③ |  | Leaf | 1PC |

**Note: Follow numbers on legs (1) and corner blocks during assembly.**





Step 1

HOOKER® FURNITURE

# ASSEMBLY INSTRUCTION

ITEM: 6700-75207-80 Leg Table w/1-24 in leaf

Diagram 1








Diagram 2

**Instruction for table leaf:**

1. There are latches at the bottom of table top, unlock the latches as shown in Diagram 1 above.

2. Pull out table top as the arrow direction shown in Diagram 2.

3. Place table leaf (3) between table tops and push table tops together.

4. Lock the latches. (See Diagram 1)

5. Take opposite actions to remove table leaf.

HOOKER®
FURNITURE

# ASSEMBLY INSTRUCTION


ITEM: 6700-75900-80 Buffet

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.
Read all instruction and study the drawing carefully before starting the assembly process .

## HARDWARE PACK


| NO. | DRAWING | DESCRIPTION | SIZE | Q'TY |
|---|---|---|---|---|
| A |  | Anti - Tip Kit | | 1 PC |

Tipping Restraint




Anti-tip kit is included for use.
We recommend installing for safety reason

A




The adjustable shelves are screwed in place to avoid damage during transit. To adjust the shelf height, remove screws then place shelf pins in the desired level.



STEP 1

STEP 2



Adjust Leveler if needed to level buffet on uneven floor.

Note: Anti-tip kit restraint is provided. Please follow the instructions enclosed with the pack.

HOOKER®
FURNITURE

# ASSEMBLY INSTRUCTION


ITEM: 6700-75906-98 Display Cabinet


Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.
Read all instruction and study the drawing carefully before starting the assembly process.

| HARDWARE LIST | | | | |
|---|---|---|---|---|
| NO. | DRAWING | DESCRIPTION | SIZE | Q'TY |
| A |  | Anti - Tip Kit | | 1PC |
| B |  | Screw | 1 1/4" | 6PCS |
| C |  | Flat Washer | 1/4" | 4PCS |
| D |  | Hanger | 75*30*38mm | 2PCS |
| E |  | Plastic Anchor | ¢ 9*30mm | 2PCS |

Tipping Restraint


Anti-tip kit is included for use. We recommend installing for safety reason








STEP 1

Mount the hanger (D) to the top of Cabinet, then attach the Cabinet to a wall.




STEP 2




To adjust the shelf height, take out shelf pins then place shelf pins in the desired level.


STEP 3



The adjustable glass shelves are packed in inner box to avoid damage during transit. Take out glass shelves from box and place them on wood shelf frames.



STEP 4



Adjust Leveler if needed to level case on uneven floor.


Note: Anti-tip kit restraint is provided. Please follow the instructions enclosed with the pack.

HOOKER®
FURNITURE

# ASSEMBLY INSTRUCTION

ITEM: 6700-75906-98 Display Cabinet

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.
Read all instruction and study the drawing carefully before starting the assembly process.



A —— male connector (of the power switch)
B —— female connector (of the power switch)
C —— male connector (of the puck light)
D —— female connector (of the puck light)
E —— male connector (of the power wire)
F —— female connector (of the power wire)





**Diagram 1**





**Diagram 2**

**Assembly Steps**

1. When each piece of cabinet is used alone, attach male connector of the power switch (A) to a wall plug. (See Diagram 1)

2. Touch dimmer is at the inside of right post.

3. If you want to bunch two or more cabinets together, place them all side by side in a desired location.

4. Leave male connector of the puck light (C) and female connector of power switch (B) for the first cabinet (#1) as it is. Keep male connector of the puck light (C) and female connector of power switch (B) off for the rest cabinets (#2, #3, and so on). (See Diagram 2)

Note: Anti-tip kit restraint is provided. Please follow the instructions enclosed with the pack.

HOOKER®
FURNITURE

# ASSEMBLY INSTRUCTION

ITEM: 6700-75906-98 Display Cabinet

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.
Read all instruction and study the drawing carefully before starting the assembly process.





**Diagram 3**

## Assembly Steps

5. Connect female connector of the puck light (D) (#1 cabinet) with male connector of power wire (E), then have female connector of power wire (F) connected to male connector of the puck light (C) (the #2 cabinet). (See Diagram 3)

6. Repeat step 5 for the 3rd cabinet and the rest of ones when more than two are bunched together till each one is connected.

7. Plug in male connector of power switch (A) (#1 cabinet).

8. Touch the dimmer of the #1 cabinet, all puck lights connecting together will be on at the same time.

Note: Anti-tip kit restraint is provided. Please follow the instructions enclosed with the pack.