HOOKER® FURNITURE

ASSEMBLY INSTRUCTION


ITEM: 6750-75200-00 Rectangle Leg Dining Table w-2-22in leaves

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.
Read all instruction and study the drawing carefully before starting the assembly process.


HARDWARE PACK


NO.	DRAWING	DESCRIPTION	SIZE	Q'TY
A		Allen Wrench	5mm	1PC
B		Bolt	$\frac{5}{16}$"	8PCS
C		Lock Washer	$\frac{5}{16}$"	8PCS
D		Flat Washer	$\frac{5}{16}$"	8PCS

PART LIST

NO.	DRAWING	DESCRIPTION	Q'TY
①		Leaf	1PC
②		Leg	4PCS
③		Top	1PC

STEP 1





Adjust Leveler if needed to level table on uneven floor.

STEP 2

HOOKER®
FURNITURE

ASSEMBLY INSTRUCTION

ITEM: 6750-75200-00 Rectangle Leg Dining Table w-2-22in leaves

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.
Read all instruction and study the drawing carefully before starting the assembly process.




Diagram 1




Diagram 2

HOOKER®
FURNITURE

ASSEMBLY INSTRUCTION

ITEM: 6750-75200-00 Rectangle Leg Dining Table w-2-22in leaves

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.
Read all instruction and study the drawing carefully before starting the assembly process.

Instruction for table leaves:

1. There are latches at the bottom of table top, unlock the latches as shown in Diagram 1 above.

2. Pull out table top as the arrow direction shown in Diagram 2.

3. Place table leaves (1) between table tops and push table tops together.

4. Lock the latches. (See Diagram 1)

5. Take opposite actions to remove table leaves.

HOOKER® FURNITURE

ASSEMBLY INSTRUCTION


ITEM: 6750-75202-95 Bistro Table


Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.
Read all instruction and study the drawing carefully before starting the assembly process.


HARDWARE PACK

NO.	DRAWING	DESCRIPTION	SIZE	Q'TY
A		Bolt	$\frac{5}{16}$"*35MM	4PCS
B		Lock Washer	$\frac{5}{16}$"	12PCS
C		Flat Washer	$\frac{5}{16}$"	12PCS
D		Allen Wrench	73*29*5MM	1PC
E		Bolt	$\frac{5}{16}$"*70MM	8PCS

PART LIST

NO.	DRAWING	DESCRIPTION	Q'TY
①		Mounting Bridge	1PC
②		Post	1PC
③		Base	1PC
④		Top	1PC





Step 1: Attach mounting bridge (1) on the post (2).

Step 2: Attach post (2) to the top (4).


Step 3: Assemble base (3) to the post (2).

HOOKER® FURNITURE

ASSEMBLY INSTRUCTION

ITEM: 6750-75202-95 Bistro Table

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.
Read all instruction and study the drawing carefully before starting the assembly process.



Adjust Leveler if needed to level table on uneven floor.

STEP 4

HOOKER® FURNITURE

ASSEMBLY INSTRUCTION

ITEM: 6750-75203B-97 Round Pedestal Dining Table Base
6750-75203T-85 Round Pedestal Dining Table Top


Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.
Read all instruction and study the drawing carefully before starting the assembly process.

HARDWARE PACK

NO.	DRAWING	DESCRIPTION	SIZE	Q'TY
A		Allen Wrench	73*29*5mm	1PC
B		Bolt	Ø5/16"	4PCS
C		Lock Washer	Ø5/16"	4PCS
D		Flat Washer	Ø5/16"	4PCS

PART LIST

NO.	DRAWING	DESCRIPTION	Q'TY
①		Top	1PC
②		Leaf	1PC
③		Base	1PC



HOOKER® FURNITURE

ASSEMBLY INSTRUCTION

ITEM: 6750-75203B-97 Round Pedestal Dining Table Base
6750-75203T-85 Round Pedestal Dining Table Top

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.
Read all instruction and study the drawing carefully before starting the assembly process.




Diagram 1




Diagram 2

Instruction for table leaf:

1. There are latches at the bottom of table top, unlock the latches as shown in Diagram 1 above.

2. Pull out table top as the arrow direction shown in Diagram 2.

3. Place table leaf (2) between table top and push table top together.

4. Lock the latches. (See Diagram 1)

5. Take opposite actions to remove table leaf.

HOOKER®

ASSEMBLY INSTRUCTION

ITEM: 6750-75211-05 Breakfast Table


Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.
Read all instruction and study the drawing carefully before starting the assembly process.

HARDWARE PACK


NO.	DRAWING	DESCRIPTION	SIZE	Q'TY
A		Bolt	$\frac{5}{16}$"	8PCS
B		Lock Washer	$\frac{5}{16}$"	8PCS
C		Flat Washer	$\frac{5}{16}$"	8PCS
D		Allen Wrench	5mm	1PC

PART LIST


NO.	DRAWING	DESCRIPTION	Q'TY
①		Top	1PC
②		Leg	4PCS



Step 1: Attach legs (2) to top (1) with flat washers (C), lock washers (B) and bolts (A), tighten all bolts with allen wrench (D).



STEP 2



Adjust Leveler if needed to level table on uneven floor.

ASSEMBLY INSTRUCTION


ITEM: 6750-75217-06 Rectangle Dining Table w/1-20in leaf

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.
Read all instruction and study the drawing carefully before starting the assembly process.

HARDWARE PACK

NO.	DRAWING	DESCRIPTION	SIZE	Q'TY
A		Allen Wrench	5mm	1PC
B		Bolt	$\frac{5}{16}$"	8PCS
C		Lock Washer	$\frac{5}{16}$"	8PCS
D		Flat Washer	$\frac{5}{16}$"	8PCS

PART LIST

NO.	DRAWING	DESCRIPTION	Q'TY
①		Leg	4PCS
②		Leaf	1PC
③		Top	1PC

STEP 1






Diagram 1



ASSEMBLY INSTRUCTION

ITEM: 6750-75217-06 Rectangle Dining Table w/1-20in leaf

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.
Read all instruction and study the drawing carefully before starting the assembly process.



STEP 2

Instruction for table leaf:

1. There are latches at the bottom of table top, unlock the latches as shown in Diagram 1 above.

2. Pull out table top as the arrow direction shown in Diagram 2.

3. Place table leaf (2) between table top and push table top together.

4. Lock the latches. (See Diagram 1)

5. Take opposite actions to remove table leaf.

HOOKER®
FURNITURE

ASSEMBLY INSTRUCTION

ITEM: 6750-75300-85 Upholstered Seat Arm Chair-2 per carton/price ea
6750-75300-97 Upholstered Seat Arm Chair-2 per carton/price ea

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.
Read all instruction and study the drawing carefully before starting the assembly process .


HARDWARE PACK

NO.	DRAWING	DESCRIPTION	SIZE	Q'TY
A		Bolt	$\frac{5}{16}$"*60mm	4PCS
B		Lock Washer	$\frac{5}{16}$"	11PCS
C		Flat Washer	$\frac{5}{16}$"	11PCS
D		Allen Wrench	73*29*5mm	1PC
E		Bolt	$\frac{5}{16}$"*70mm	5PCS
F		Bolt	$\frac{5}{16}$"*40mm	2PCS
G		Screw		2PCS

PART LIST


NO.	DRAWING	DESCRIPTION	Q'TY
①		Back Frame	1PC
②		Arm	2PCS
③		Seat Frame	1PC
④		Leg	2PCS

***Note: Please follow numbers on legs, arms and corner blocks during assembly.**



Step 3: Assemble arms (2) to back frame (1) and seat frame (3).

Step 2: Attach legs (4) to seat frame (3).




Step 1: Attach seat frame (3) to back frame (1).

HOOKER®
FURNITURE

ASSEMBLY INSTRUCTION

ITEM: 6750-75300-85 Upholstered Seat Arm Chair-2 per carton/price ea
6750-75300-97 Upholstered Seat Arm Chair-2 per carton/price ea

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.
Read all instruction and study the drawing carefully before starting the assembly process .



PLEASE READ THESE INSTRUCTIONS PRIOR TO ASSEMBLING THE CHAIRS
CHAIR LEVELING INSTRUCTION SUPPLEMENT

Chair leveling procedures:

To make the assembly process easy and efficient, please read the entire instruction sheet prior to assembling of the chair. Make sure all hardware listed is included. To properly assemble the chair, none of the bolts should be fully tightened until all components are attached to the chair. This will allow an opportunity to level the chair and prevent any unnecessary “rocking”.

1. Place the loosely assembled chair on a hard flat surface.
2. Apply gentle downward pressure on the seat. This step eliminates rocking and ensures the chair to be level.
3. Once the chair is level, tighten all bolts and nuts.

Note:

Most floors have slight irregularities that can affect chair leveling. If your chair is uneven when placed in its desired location, perform the following steps:

1. Loosen front legs to finger tight.

2. Extend both front legs upward to their fullest length.

3. Gently push downward on the front edge of the seat until all four legs rest on the floor.

4. Re-tighten all bolts and nuts.

HOOKER® FURNITURE

ASSEMBLY INSTRUCTION

ITEM: 6750-75310-85 Upholstered Seat Side Chair-2 per carton/price ea
6750-75310-97 Upholstered Seat Side Chair-2 per carton/price ea

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.
Read all instruction and study the drawing carefully before starting the assembly process .


HARDWARE PACK

NO.	DRAWING	DESCRIPTION	SIZE	Q'TY
A		Bolt	$\frac{5}{16}$"*60mm	4PCS
B		Lock Washer	$\frac{5}{16}$"	9PCS
C		Flat Washer	$\frac{5}{16}$"	9PCS
D		Allen Wrench	73*29*5mm	1PC
E		Bolt	$\frac{5}{16}$"*70mm	5PCS

PART LIST

NO.	DRAWING	DESCRIPTION	Q'TY
①		Back Frame	1PC
②		Seat Frame	1PC
③		Leg	2PCS

***Note: Please follow numbers on legs and corner blocks during assembly.**



Step 2: Attach legs (3) to seat frame (2).


Step 1: Attach seat frame (2) to back frame (1).

HOOKER®
FURNITURE

ASSEMBLY INSTRUCTION

ITEM: 6750-75310-85 Upholstered Seat Side Chair-2 per carton/price ea
6750-75310-97 Upholstered Seat Side Chair-2 per carton/price ea

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.
Read all instruction and study the drawing carefully before starting the assembly process .



PLEASE READ THESE INSTRUCTIONS PRIOR TO ASSEMBLING THE CHAIRS
CHAIR LEVELING INSTRUCTION SUPPLEMENT

Chair leveling procedures:

To make the assembly process easy and efficient, please read the entire instruction sheet prior to assembling of the chair. Make sure all hardware listed is included. To properly assemble the chair, none of the bolts should be fully tightened until all components are attached to the chair. This will allow an opportunity to level the chair and prevent any unnecessary “rocking”.

1. Place the loosely assembled chair on a hard flat surface.
2. Apply gentle downward pressure on the seat. This step eliminates rocking and ensures the chair to be level.
3. Once the chair is level, tighten all bolts and nuts.

Note:

Most floors have slight irregularities that can affect chair leveling. If your chair is uneven when placed in its desired location, perform the following steps:

1. Loosen front legs to finger tight.

2. Extend both front legs upward to their fullest length.

3. Gently push downward on the front edge of the seat until all four legs rest on the floor.

4. Re-tighten all bolts and nuts.

HOOKER®
FURNITURE

ASSEMBLY INSTRUCTION


ITEM: 6750-75410-05 Upholstered Seat Side Chair-2 per carton/price ea
6750-75410-32 Upholstered Seat Side Chair-2 per carton/price ea
6750-75410-40 Upholstered Seat Side Chair-2 per carton/price ea
6750-75410-95 Upholstered Seat Side Chair-2 per carton/price ea


Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.
Read all instruction and study the drawing carefully before starting the assembly process.

HARDWARE PACK

NO.	DRAWING	DESCRIPTION	SIZE	Q'TY
A		Bolt	$\frac{5}{16}$"*60mm	4PCS
B		Lock Washer	$\frac{5}{16}$"	9PCS
C		Flat Washer	$\frac{5}{16}$"	9PCS
D		Allen Wrench	73*29*5mm	1PC
E		Bolt	$\frac{5}{16}$"*70mm	5PCS

PART LIST

NO.	DRAWING	DESCRIPTION	Q'TY
①		Back Frame	1PC
②		Leg	2PCS
③		Seat Frame	1PC



Step 2: Attach legs (2) to seat frame (3).

Step 1: Attach seat frame (3) to back frame (1).

HOOKER®
FURNITURE

ASSEMBLY INSTRUCTION

ITEM: 6750-75410-05 Upholstered Seat Side Chair-2 per carton/price ea
6750-75410-32 Upholstered Seat Side Chair-2 per carton/price ea
6750-75410-40 Upholstered Seat Side Chair-2 per carton/price ea
6750-75410-95 Upholstered Seat Side Chair-2 per carton/price ea

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.
Read all instruction and study the drawing carefully before starting the assembly process.



PLEASE READ THESE INSTRUCTIONS PRIOR TO ASSEMBLING THE CHAIRS
CHAIR LEVELING INSTRUCTION SUPPLEMENT

Chair leveling procedures:

To make the assembly process easy and efficient, please read the entire instruction sheet prior to assembling of the chair. Make sure all hardware listed is included. To properly assemble the chair, none of the bolts should be fully tightened until all components are attached to the chair. This will allow an opportunity to level the chair and prevent any unnecessary “rocking”.

1. Place the loosely assembled chair on a hard flat surface.
2. Apply gentle downward pressure on the seat. This step eliminates rocking and ensures the chair to be level.
3. Once the chair is level, tighten all bolts and nuts.

Note:

Most floors have slight irregularities that can affect chair leveling. If your chair is uneven when placed in its desired location, perform the following steps:

1. Loosen front legs to finger tight.

2. Extend both front legs upward to their fullest length.

3. Gently push downward on the front edge of the seat until all four legs rest on the floor.

4. Re-tighten all bolts and nuts.

HOOKER®
FURNITURE

ASSEMBLY INSTRUCTION

ITEM: 6750-75500-37 Host Chair-2 per carton/price ea


Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.
Read all instruction and study the drawing carefully before starting the assembly process .

HARDWARE PACK


NO.	DRAWING	DESCRIPTION	SIZE	Q'TY
A		Bolt	$\frac{5}{16}$"	8PCS
B		Lock Washer	$\frac{5}{16}$"	8PCS
C		Flat Washer	$\frac{5}{16}$"	8PCS
D		Allen Wrench	73*29*5mm	1PC

PART LIST

NO.	DRAWING	DESCRIPTION	Q'TY
①		Seat	1PC
②		Front Leg	2PCS
③		Back Leg	2PCS



STEP 1




HOOKER®
FURNITURE

ASSEMBLY INSTRUCTION

ITEM: 6750-75500-37 Host Chair-2 per carton/price ea

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.
Read all instruction and study the drawing carefully before starting the assembly process.



PLEASE READ THESE INSTRUCTIONS PRIOR TO ASSEMBLING THE CHAIRS
CHAIR LEVELING INSTRUCTION SUPPLEMENT

Chair leveling procedures:

To make the assembly process easy and efficient, please read the entire instruction sheet prior to assembling of the chair. Make sure all hardware listed is included. To properly assemble the chair, none of the bolts should be fully tightened until all components are attached to the chair. This will allow an opportunity to level the chair and prevent any unnecessary “rocking”.

1. Place the loosely assembled chair on a hard flat surface.
2. Apply gentle downward pressure on the seat. This step eliminates rocking and ensures the chair to be level.
3. Once the chair is level, tighten all bolts and nuts.

Note:

Most floors have slight irregularities that can affect chair leveling. If your chair is uneven when placed in its desired location, perform the following steps:

1. Loosen front legs to finger tight.

2. Extend both front legs upward to their fullest length.

3. Gently push downward on the front edge of the seat until all four legs rest on the floor.

4. Re-tighten all bolts and nuts.

HOOKER®
FURNITURE

ASSEMBLY INSTRUCTION

ITEM: 6750-75600-85 Upholstered Arm Chair-2 per carton/price ea


Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.
Read all instruction and study the drawing carefully before starting the assembly process.

HARDWARE PACK

NO.	DRAWING	DESCRIPTION	SIZE	Q'TY
A		Bolt	$\frac{5}{16}$"	8PCS
B		Lock Washer	$\frac{5}{16}$"	8PCS
C		Flat Washer	$\frac{5}{16}$"	8PCS
D		Allen Wrench	73*29*5mm	1PC

PART LIST

NO.	DRAWING	DESCRIPTION	Q'TY
①		Seat	1PC
②		Front Leg	2PCS
③		Back Leg	2PCS




Note: Anti-tip kit restraint is provided. Please follow the instructions enclosed with the pack.

HOOKER®
FURNITURE

ASSEMBLY INSTRUCTION

ITEM: 6750-75600-85 Upholstered Arm Chair-2 per carton/price ea

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.
Read all instruction and study the drawing carefully before starting the assembly process.



PLEASE READ THESE INSTRUCTIONS PRIOR TO ASSEMBLING THE CHAIRS
CHAIR LEVELING INSTRUCTION SUPPLEMENT

Chair leveling procedures:

To make the assembly process easy and efficient, please read the entire instruction sheet prior to assembling of the chair. Make sure all hardware listed is included. To properly assemble the chair, none of the bolts should be fully tightened until all components are attached to the chair. This will allow an opportunity to level the chair and prevent any unnecessary “rocking”.

1. Place the loosely assembled chair on a hard flat surface.
2. Apply gentle downward pressure on the seat. This step eliminates rocking and ensures the chair to be level.
3. Once the chair is level, tighten all bolts and nuts.

Note:

Most floors have slight irregularities that can affect chair leveling. If your chair is uneven when placed in its desired location, perform the following steps:

1. Loosen front legs to finger tight.

2. Extend both front legs upward to their fullest length.

3. Gently push downward on the front edge of the seat until all four legs rest on the floor.

4. Re-tighten all bolts and nuts.

Note: Anti-tip kit restraint is provided. Please follow the instructions enclosed with the pack.

HOOKER®
FURNITURE

ASSEMBLY INSTRUCTION

ITEM: 6750-75610-85 Upholstered Side Chair-2 per carton/price ea


Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.
Read all instruction and study the drawing carefully before starting the assembly process .

HARDWARE PACK


NO.	DRAWING	DESCRIPTION	SIZE	Q'TY
A		Bolt	$\frac{5}{16}$"	8PCS
B		Lock Washer	$\frac{5}{16}$"	8PCS
C		Flat Washer	$\frac{5}{16}$"	8PCS
D		Allen Wrench	73*29*5mm	1PC

PART LIST

NO.	DRAWING	DESCRIPTION	Q'TY
①		Seat	1PC
②		Front Leg	2PCS
③		Back Leg	2PCS



STEP 1




HOOKER®
FURNITURE

ASSEMBLY INSTRUCTION

ITEM: 6750-75610-85 Upholstered Side Chair-2 per carton/price ea

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.
Read all instruction and study the drawing carefully before starting the assembly process .



PLEASE READ THESE INSTRUCTIONS PRIOR TO ASSEMBLING THE CHAIRS
CHAIR LEVELING INSTRUCTION SUPPLEMENT

Chair leveling procedures:

To make the assembly process easy and efficient, please read the entire instruction sheet prior to assembling of the chair. Make sure all hardware listed is included. To properly assemble the chair, none of the bolts should be fully tightened until all components are attached to the chair. This will allow an opportunity to level the chair and prevent any unnecessary “rocking”.

1. Place the loosely assembled chair on a hard flat surface.
2. Apply gentle downward pressure on the seat. This step eliminates rocking and ensures the chair to be level.
3. Once the chair is level, tighten all bolts and nuts.

Note:

Most floors have slight irregularities that can affect chair leveling. If your chair is uneven when placed in its desired location, perform the following steps:

1. Loosen front legs to finger tight.

2. Extend both front legs upward to their fullest length.

3. Gently push downward on the front edge of the seat until all four legs rest on the floor.

4. Re-tighten all bolts and nuts.

HOOKER®
FURNITURE


ASSEMBLY INSTRUCTION

ITEM: 6750-75900-85 Four-Door Buffet

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.
Read all instruction and study the drawing carefully before starting the assembly process.

HARDWARE PACK

NO.	DRAWING	DESCRIPTION	SIZE	Q'TY
A		Anti - Tip Kit		1PC



Note: Anti-tip kit restraint is provided. Please follow the instructions enclosed with the pack.

HOOKER®
FURNITURE

ASSEMBLY INSTRUCTION


ITEM: 6750-75906-00 Display Cabinet


Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.
Read all instruction and study the drawing carefully before starting the assembly process.

HARDWARE LIST				
NO.	DRAWING	DESCRIPTION	SIZE	Q'TY
A		Anti - Tip Kit		1PC
B		Screw	1 1/4"	6PCS
C		Flat Washer	1/4"	4PCS
D		Hanger	75*30*38mm	2PCS
E		Plastic Anchor	¢ 9*30mm	2PCS

Tipping Restraint


Anti-tip kit is included for use. We recommend installing for safety reason





STEP 1

Mount the hanger (D) to the top of Cabinet, then attach the Cabinet to a wall.




Note: Anti-tip kit restraint is provided. Please follow the instructions enclosed with the pack.

HOOKER®
FURNITURE

ASSEMBLY INSTRUCTION

ITEM: 6750-75906-00 Display Cabinet

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.
Read all instruction and study the drawing carefully before starting the assembly process.



The adjustable glass shelves are packed in inner box to avoid damage during transit. Take out glass shelves from box and place them on wood shelf frames.

To adjust the shelf height, take out shelf pins then place shelf pins in the desired level.

Adjust Leveler if needed to level case on uneven floor.

Note: Anti-tip kit restraint is provided. Please follow the instructions enclosed with the pack.