


ITEM: 6820-75200T-80 Rectangle Dining Table Top
 6820-75200T-85 Rectangle Dining Table Top
 6820-75200T-99 Rectangle Dining Table Top
 6820-75200B-80 Rectangle Dining Table Base
 6820-75200B-85 Rectangle Dining Table Base
 6820-75200B-99 Rectangle Dining Table Base

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process.

HARDWARE PACK				
NO.	DRAWING	DESCRIPTION	SIZE	Q'TY
A		Allen Wrench	73*29*5mm	1 PC
B		Bolt	5/16*40mm	8 PCS
C		Lock Washer	5/16"	8 PCS
D		Flat Washer	5/16*22mm	8 PCS
E		Threaded Rod	3/8*100mm	2 PCS
F		Flat Washer	3/8*22mm	2 PCS
G		Lock Washer	3/8"	2 PCS
H		Nut	3/8"	2 PCS
K		Open Wrench		1 PC

PART LIST			
NO.	DRAWING	DESCRIPTION	Q'TY
①		Table Top	1 PC
②		Base	2 PCS
③		Bottom Rail	1 PC
④		Leaf	2 PCS

ASSEMBLY INSTRUCTION

ITEM: 6820-75200T-80 Rectangle Dining Table Top
6820-75200T-85 Rectangle Dining Table Top
6820-75200T-99 Rectangle Dining Table Top
6820-75200B-80 Rectangle Dining Table Base
6820-75200B-85 Rectangle Dining Table Base
6820-75200B-99 Rectangle Dining Table Base

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.


Read all instruction and study the drawing carefully before starting the assembly process.

STEP 1:

Attach base (2) and bottom rail (3) with threaded rod (E) by open wrench (K).

STEP 2:

Insert bolts (B) to base (2) and tighten to table top (1) by allen wrench (A).




ASSEMBLY INSTRUCTION

ITEM: 6820-75200T-80 Rectangle Dining Table Top
6820-75200T-85 Rectangle Dining Table Top
6820-75200T-99 Rectangle Dining Table Top
6820-75200B-80 Rectangle Dining Table Base
6820-75200B-85 Rectangle Dining Table Base
6820-75200B-99 Rectangle Dining Table Base

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process.



STEP 3:

Pull out both ends of table top (1) as the arrow direction, place the leaf (4) between and push them together, lock the latches.

Adjust leveler if needed to level table on uneven floor.

Note: Take opposite actions to remove table leaf.

ITEM: 6820-75203B-80 Round Dining Table Base
 6820-75203B-85 Round Dining Table Base
 6820-75203B-99 Round Dining Table Base
 6820-75203T-80 72in Round Dining Table Top
 6820-75203T-85 72in Round Dining Table Top
 6820-75203T-99 72in Round Dining Table Top


Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process.


HARDWARE PACK				
NO.	DRAWING	DESCRIPTION	SIZE	Q'TY
A		Allen Wrench	73*29*5mm	1 PC
B		Bolt	5/16*50mm	8 PCS
C		Bolt	5/16*35mm	7 PCS
D		Lock Washer	5/16"	15 PCS
E		Flat Washer	5/16*22mm	15 PCS

PART LIST			
NO.	DRAWING	DESCRIPTION	Q'TY
1		Leg Frame	1 PC
2		Square Frame	1 PC
3		Stretcher	1 PC
4		Mounting Bridge	1 PC
5		Top Panel	1 PC

STEP 1:
 Assemble Leg frame (1) with
 Square Frame (2).



STEP 2:
 Attach Stretcher (3) to the Leg Frame (1)
 and Square Frame (2).




ASSEMBLY INSTRUCTION

ITEM: 6820-75203B-80 Round Dining Table Base
6820-75203B-85 Round Dining Table Base
6820-75203B-99 Round Dining Table Base
6820-75203T-80 72in Round Dining Table Top
6820-75203T-85 72in Round Dining Table Top
6820-75203T-99 72in Round Dining Table Top

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process.




ASSEMBLY INSTRUCTION

ITEM: 6820-75203B-80 Round Dining Table Base
6820-75203B-85 Round Dining Table Base
6820-75203B-99 Round Dining Table Base
6820-75203T-80 72in Round Dining Table Top
6820-75203T-85 72in Round Dining Table Top
6820-75203T-99 72in Round Dining Table Top


Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process.



STEP 4:

Attach the complete base to
Top Panel (5).



Adjust leveler if needed to
level table on uneven floor.



ITEM: 6820-75213-80 48in Round Dining Table
6820-75213-85 48in Round Dining Table
6820-75213-99 48in Round Dining Table


Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process.

HARDWARE PACK					PART LIST			
NO.	DRAWING	DESCRIPTION	SIZE	Q'TY	NO.	DRAWING	DESCRIPTION	Q'TY
A		Allen Wrench	73*29*5mm	1 PC	1		Leg Frame	1 PC
B		Bolt	5/16*50mm	8 PCS	2		Square Frame	1 PC
C		Bolt	5/16*35mm	7 PCS	3		Stretcher	1 PC
D		Lock Washer	5/16"	15 PCS	4		Mounting Bridge	1 PC
E		Flat Washer	5/16*22mm	15 PCS	5		Top Panel	1 PC


Step 1:

Assemble leg frame (1) with square frame (2).



Step 2:

Attach stretchers (3) to the leg frame (1) and square frame (2).




ASSEMBLY INSTRUCTION

ITEM: 6820-75213-80 48in Round Dining Table
6820-75213-85 48in Round Dining Table
6820-75213-99 48in Round Dining Table

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.


Read all instruction and study the drawing carefully before starting the assembly process.




ITEM: 6820-75213-80 48in Round Dining Table
6820-75213-85 48in Round Dining Table
6820-75213-99 48in Round Dining Table

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process.



Step 4:
Attach the complete base to top panel (5).



Adjust leveler if needed to
level table on uneven floor.



ITEM: 6820-75203B-80 Round Dining Table Base
 6820-75203B-85 Round Dining Table Base
 6820-75203B-99 Round Dining Table Base
 6820-75223T-80 60in Round Dining Table Top
 6820-75223T-85 60in Round Dining Table Top
 6820-75223T-99 60in Round Dining Table Top

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.


Read all instruction and study the drawing carefully before starting the assembly process.

HARDWARE PACK				
NO.	DRAWING	DESCRIPTION	SIZE	Q'TY
A		Allen Wrench	73*29*5mm	1 PC
B		Bolt	5/16*50mm	8 PCS
C		Bolt	5/16*35mm	7 PCS
D		Lock Washer	5/16"	15 PCS
E		Flat Washer	5/16*22mm	15 PCS

PART LIST			
NO.	DRAWING	DESCRIPTION	Q'TY
1		Leg Frame	1 PC
2		Square Frame	1 PC
3		Stretcher	1 PC
4		Mounting Bridge	1 PC
5		Top Panel	1 PC


STEP 1:

Assemble Leg frame (1) with Square Frame (2).



STEP 2:

Attach Stretcher (3) to the Leg Frame (1) and Square Frame (2).



ASSEMBLY INSTRUCTION


ITEM: 6820-75203B-80 Round Dining Table Base
6820-75203B-85 Round Dining Table Base
6820-75203B-99 Round Dining Table Base
6820-75223T-80 60in Round Dining Table Top
6820-75223T-85 60in Round Dining Table Top
6820-75223T-99 60in Round Dining Table Top

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process.

STEP 3:

Attach Mounting Bridge (4) to the base.




ASSEMBLY INSTRUCTION

ITEM: 6820-75203B-80 Round Dining Table Base
6820-75203B-85 Round Dining Table Base
6820-75203B-99 Round Dining Table Base
6820-75223T-80 60in Round Dining Table Top
6820-75223T-85 60in Round Dining Table Top
6820-75223T-99 60in Round Dining Table Top


Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process.



STEP 4:
Attach the complete base to
Top Panel (5).

Adjust leveler if needed to
level table on uneven floor.






ITEM: 6820-75311-80 Splatback Side Chair 2 per carton - price ea
6820-75311-85 Splatback Side Chair 2 per carton - price ea
6820-75311-99 Splatback Side Chair 2 per carton - price ea

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process.



HARDWARE PACK				
NO.	DRAWING	DESCRIPTION	SIZE	Q'TY
A		Allen Wrench	73*29*5mm	1 PC
B		Bolt	5/16*80mm	5 PCS
C		Bolt	5/16*50mm	4 PCS
D		Lock Washer	5/16"	9 PCS
E		Flat Washer	5/16*16mm	9 PCS
F		Screw		4 PCS

PARTS LIST			
NO.	DRAWING	DESCRIPTION	Q'TY
1		Back Frame	1 PC
2		Seat Frame	1 PC
3		Stretcher	1 PC
4		Left Front Leg	1 PC
5		Right Front Leg	1 PC

Note: There are two K/D chairs in one box. Please follow numbers on one chair and letters on the other chair during assembly.

STEP 1:

Assemble Seat frame (2) to Back Frame (1)
by using Bolts (B), Lock Washers (D),
Flat Washers (E) and Allen wrench (A).




STEP 2:

Assemble Stretcher (3) to Back Frame (1).


ITEM: 6820-75311-80 Splatback Side Chair 2 per carton - price ea
6820-75311-85 Splatback Side Chair 2 per carton - price ea
6820-75311-99 Splatback Side Chair 2 per carton - price ea

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.


Read all instruction and study the drawing carefully before starting the assembly process.



STEP 4:
Tighten the Stretcher and Legs by
using Screw (F).



STEP 3:
Follow numbers (or letters) on legs and
corner blocks, attach Front Legs (4 & 5)
to Seat Frame (3) by using bolts (C),
lock washers (D), flat washers (E)
and Allen wrench (1).



ITEM: 6820-75311-80 Splatback Side Chair 2 per carton - price ea
6820-75311-85 Splatback Side Chair 2 per carton - price ea
6820-75311-99 Splatback Side Chair 2 per carton - price ea

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.


Read all instruction and study the drawing carefully before starting the assembly process.

PLEASE READ THESE INSTRUCTIONS PRIOR TO ASSEMBLING THE CHAIRS CHAIR LEVELING INSTRUCTION SUPPLEMENT

Chair leveling procedures:

To make the assembly process easy and efficient, please read the entire instruction sheet prior to assembling of the chair. Make sure all hardware listed is included. To properly assemble the chair, none of the bolts should be fully tightened until all components are attached to the chair. This will allow an opportunity to level the chair and prevent any unnecessary "rocking".

1. Place the loosely assembled chair on a hard flat surface.
2. Apply gentle downward pressure on the seat. This step eliminates rocking and ensures the chair to be level.
3. Once the chair is level, tighten all bolts and nuts.



Note:

Most floors have slight irregularities that can affect chair leveling. If your chair is uneven when placed in its desired location, perform the following steps:

1. Loosen front legs to finger tight.
2. Extend both front legs upward to their fullest length.
3. Gently push downward on the front edge of the seat until all four legs rest on the floor.
4. Re-tighten all bolts and nuts.

ASSEMBLY INSTRUCTION

ITEM: 6820-75900B-80 Sideboard

6820-75900B-85 Sideboard

6820-75900B-99 Sideboard

6820-75900T-80 Display Hutch

6820-75900T-85 Display Hutch

6820-75900T-99 Display Hutch

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process.

HARDWARE PACK				
NO.	DRAWING	DESCRIPTION	SIZE	Q'TY
A		Allen Wrench	69*27.2*4mm	1 PC
B		Bolt	1/4*19mm	8 PCS
C		Lock Washer	1/4(6mm)	8 PCS
D		Flat Washer	1/4*16mm	8 PCS
E		Mending Plate	100*25*2mm	3 PCS
F		Hanger	75*30*38mm	2 PCS
G		Screw	8#*11/4	2 PCS
H		Plastic Anchor		2 PCS

PARTS LIST				
NO.	DRAWING	DESCRIPTION	SIZE	Q'TY
1		Display Hutch		1 PC
2		Sideboard		1 PC


ITEM: 6820-75900B-80 Sideboard
6820-75900B-85 Sideboard
6820-75900B-99 Sideboard
6820-75900T-80 Display Hutch
6820-75900T-85 Display Hutch
6820-75900T-99 Display Hutch

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process.

Assembly steps for connecting Sideboard (2) and Display Hutch (1):

Place Display Hutch (1) on top of Sideboard (2), then secure them via mending plates (E) by using bolts (B), lock washers (C), flat washers (D) and Allen wrench (A).



ASSEMBLY INSTRUCTION

ITEM: 6820-75900B-80 Sideboard

6820-75900B-85 Sideboard

6820-75900B-99 Sideboard


6820-75900T-80 Display Hutch

6820-75900T-85 Display Hutch

6820-75900T-99 Display Hutch

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process.



ITEM: 6820-75900B-80 Sideboard

6820-75900B-85 Sideboard

6820-75900B-99 Sideboard

6820-75900T-80 Display Hutch

6820-75900T-85 Display Hutch

6820-75900T-99 Display Hutch

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process.

HARDWARE PACK				
NO.	DRAWING	DESCRIPTION	SIZE	Q'TY
A		Allen Wrench	69*27.2*4mm	1 PC
B		Bolt	1/4*19mm	8 PCS
C		Lock Washer	1/4(6mm)	8 PCS
D		Flat Washer	1/4*16mm	8 PCS
E		Mending Plate	100*25*2mm	3 PCS
F		Hanger	75*30*38mm	2 PCS
G		Screw	8#*11/4	2 PCS
H		Plastic Anchor		2 PCS

PARTS LIST				
NO.	DRAWING	DESCRIPTION	SIZE	Q'TY
1		Display Hutch		1 PC
2		Sideboard		1 PC


ITEM: 6820-75900B-80 Sideboard
6820-75900B-85 Sideboard
6820-75900B-99 Sideboard
6820-75900T-80 Display Hutch
6820-75900T-85 Display Hutch
6820-75900T-99 Display Hutch

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process.

Assembly steps for connecting Sideboard (2) and Display Hutch (1):

Place Display Hutch (1) on top of Sideboard (2), then secure them via mending plates (E) by using bolts (B), lock washers (C), flat washers (D) and Allen wrench (A).



ASSEMBLY INSTRUCTION

ITEM: 6820-75900B-80 Sideboard

6820-75900B-85 Sideboard

6820-75900B-99 Sideboard


6820-75900T-80 Display Hutch

6820-75900T-85 Display Hutch

6820-75900T-99 Display Hutch

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process.



ITEM: 6820-75901-80 Buffet
6820-75901-85 Buffet
6820-75901-99 Buffet


Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process.



HARDWARE PACK

NO.	DRAWING	DESCRIPTION	SIZE	Q'TY
A		Anti - Tip Kit		1 PC


Tipping Restraint



Anti-tip kit is included for use.
We recommend installing for
safety reason.



Adjust leveler if needed to level
buffet on uneven floor.




The adjustable shelf is
screwed in place to avoid
damage during transit.
To adjust the shelf height,
remove screws then
place shelf pins in the
desired level.

ITEM: 6820-75906-80 Display Cabinet
6820-75906-85 Display Cabinet
6820-75906-99 Display Cabinet


Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process.

HARDWARE PACK				
NO.	DRAWING	DESCRIPTION	SIZE	Q'TY
A		Bolt	1/4"x19mm	2 PCS
B		Lock washer	Ø1/4"	2 PCS
C		Flat washer	Ø1/4"x16mm	2 PCS
D		Allen Wrench	4mm	1 PC
E		Hanger	75*30*38mm	2 PCS
F		Screw	8#*11/4	2 PCS
G		Plastic Anchor		2 PCS



STEP 1:
Mount the hanger (E) to top of the cabinet, then attach the cabinet to a wall.



STEP 2:
The adjustable shelves are screwed in place to avoid damage during transit. To adjust the shelf height, remove screws then place shelf pins in the desired level.

Adjust leveler if needed to level cabinet on uneven floor.

