



ITEM: 6950-75201T-80 Pole Rattan Round Dining Table Top
 6950-75201B-80 Pole Rattan Round Dining Table Base
 6950-75201T-99 Pole Rattan Round Dining Table Top
 6950-75201B-99 Pole Rattan Round Dining Table Base


Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process.


HARDWARE PACK				
NO.	DRAWING	DESCRIPTION	SIZE	Q'TY
A		Allen Wrench	73*29*5mm	1 PC
B		Bolt	Ø5/16"	16 PCS
C		Lock Washer	Ø5/16"	16 PCS
D		Flat Washer	Ø5/16"	16 PCS
E		Open Wrench	14mm	1 PC
F		Nut	Ø3/8"	4 PCS
G		Lock Washer	Ø3/8"	4 PCS
H		Flat Washer	Ø3/8"	4 PCS
I		Threaded Rod	Ø3/8"	4 PCS
J		Screw	1 1/2"	4 PCS
K		Wood Cap	48*29*37mm	4 PCS

PART LIST			
NO.	DRAWING	DESCRIPTION	Q'TY
1		Leg Post	4 PCS
2		Leaf	1 PC
3		Table Top	1 PC
4		Stretcher	1 PC
5		Mounting Plate	1 PC

Step 2:
 Attached wood caps (K) to stretcher (4).




Step 1:
 Attached leg posts (1) to stretcher (4).




ITEM: 6950-75201T-80 Pole Rattan Round Dining Table Top
6950-75201B-80 Pole Rattan Round Dining Table Base
6950-75201T-99 Pole Rattan Round Dining Table Top
6950-75201B-99 Pole Rattan Round Dining Table Base

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process.

**Step 3:**

Attached mounting plate (5) to the top of the leg posts (1).

**Step 4:**


Attached table base to table top (3).

ASSEMBLY INSTRUCTION

ITEM: 6950-75201T-80 Pole Rattan Round Dining Table Top
 6950-75201B-80 Pole Rattan Round Dining Table Base
 6950-75201T-99 Pole Rattan Round Dining Table Top
 6950-75201B-99 Pole Rattan Round Dining Table Base


Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process.




Step 5:

Unlock the latches at the bottom of table top (3).





Step 6:

Pull out both ends of table top (3) as the arrow direction, place the leaf (2) between and push them together, lock the latches.



Note: Take opposite actions to remove table leaf.



Adjust leveler if needed to level table on uneven floor.


Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process.

HARDWARE PACK				
NO.	DRAWING	DESCRIPTION	SIZE	Q'TY
A		Bolt	5/16"*80mm	4 PCS
B		Lock Washer	Ø5/16"	9 PCS
C		Flat Washer	Ø5/16"	9 PCS
D		Allen Wrench	73*29*5mm	1 PC
E		Bolt	5/16"*60mm	4 PCS
F		Screw	1 1/4"	4 PCS
G		Bolt	5/16"*70mm	1 PC

PARTS LIST			
NO.	DRAWING	DESCRIPTION	Q'TY
1		Back Leg Frame	1 PC
2		Front Leg	2 PCS
3		Seat Frame	1 PC
4		Stretchers	1 PC

Note: There are two K/D chairs in one box. Please follow numbers on one chair and letters on the other chair during assembly.



ITEM: 6950-75310-80 Cane Back Side Chair - 2 per ctn/price each

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process.


PLEASE READ THESE INSTRUCTIONS PRIOR TO ASSEMBLING THE CHAIRS

CHAIR LEVELING INSTRUCTION SUPPLEMENT

Chair leveling procedures:

To make the assembly process easy and efficient, please read the entire instruction sheet prior to assembling of the chair. Make sure all hardware listed is included. To properly assemble the chair, none of the bolts should be fully tightened until all components are attached to the chair. This will allow an opportunity to level the chair and prevent any unnecessary "rocking".

1. Place the loosely assembled chair on a hard flat surface.
2. Apply gentle downward pressure on the seat. This step eliminates rocking and ensures the chair to be level.
3. Once the chair is level, tighten all bolts and nuts.



Note:

Most floors have slight irregularities that can affect chair leveling. If your chair is uneven when placed in its desired location, perform the following steps:

1. Loosen front legs to finger tight.
2. Extend both front legs upward to their fullest length.
3. Gently push downward on the front edge of the seat until all four legs rest on the floor.
4. Re-tighten all bolts and nuts.