


ASSEMBLY INSTRUCTION

(for connecting the wire of the light on this curio)

Item#: 5070-50001 Bunching Curio

*** Caution: Please read all instructions carefully before starting the assembly process.

Please note the curio can be used alone with can light on by a touch dimmer. Also, when 2 or more are bunched together, you can control all can lights by touching one dimmer.



- A — male connector (of the power switch)
- B — female connector (of the power switch)
- C — male connector (of the bulb)
- D — female connector (of the bulb)
- E — male connector (of the power wire)
- F — female connector (of the power wire)




DIAGRAM 1




DIAGRAM 2

Assembly steps:

1. When each piece of curio is used alone, attach male connector of the power switch (A) to a wall plug. (see diagram 1)
2. Touch the dimmer at the right top of door hinge, the can light of it will be on.
3. If you want to bunch 2 or more curios together, place them all side by side in a desired location.
4. Leave male connector of the bulb (C) and female connector of power Switch (B) for the first curio (#1) as it is. Keep male connector of the bulb (C) and female connector of power switch (B) off for the rest curios(#2, #3, and so on). See diagram 2.
5. Connect female connector of the bulb(D) (the #1 curio) with male connector of power wire (E), then have female connector of power wire(F) connected to male connector of the bulb(C) (the #2 curio). See diagram 3.




DIAGRAM 3

6. Repeat step 5 for the 3rd curio and the rest ones when more than 2 are bunched together till each one is connected.
7. Attach male connector of power switch (A)(the #1 curio) to a wall plug.
8. Touch the dimmer of the #1 curio, all can lights connecting together will be on at the same time.

Cleaning Instruction: Clean finished parts with a mild dishwashing liquid and water solution on a damp cloth. Polish the finish with soft cloth and an industry recognized furniture polish.

ASSEMBLY INSTRUCTION

Item#: 5070-75001 Round Dining Table Base(C)

Item#: 5070-75002 Round Dining Table Top(C)

Item#: 5070-75012 Round Urn Table Top

*** Please make sure you have all parts indicated below prior to assembly.
This unit is heavy and can best be assembled with the help of two or more people.

NO.	HARDWARE LIST		Q'TY
A		ALLEN WRENCH	1
B		$\frac{5}{16}$ "*35MM BOLT	4
C		$\frac{5}{16}$ " LOCK WASHER	8
D		$\frac{5}{16}$ " FLAT WAHSER	8
E		$\frac{5}{16}$ "*40MM BOLT	4




DIAGRAM 1




DIAGRAM 2

Assembly steps:

1. Place the base upright, use 4 bolts (E), 4 lock washers (C) and 4 flat washers(D) to attach the mounting bridge to the base, and tighten all bolts securely with allen wrench (A) (See diagram 1).
2. Put the top on the base, align the holes on the top with the dowels (F) on the mounting bridge, use 4 bolts (B), 4 lock washers (C) and 4 flat washers(D), and tighten all bolts securely with allen wrench (A) (See diagram 2).

Cleaning Instruction: Clean finished parts with a mild dishwashing liquid and water solution on a damp cloth.
Polish the finish with soft cloth and an industry recognized furniture polish.

ASSEMBLY INSTRUCTION

Item#: 5070-75007 Rectangle Dining Table Base
5070-75008 Rectangle Dining Table Top

*****Please make sure you have all parts indicated below prior to assembly.**
This unit is heavy and can best be assembled with the help of two or more people.

NO.	HARDWARE LIST		Q'TY
A		ALLEN WRENCH	1
B		$\frac{5}{16}$ "*35mm BOLT	8
C		$\frac{5}{16}$ " LOCK WASHER	12
D		$\frac{5}{16}$ " FLAT WASHER	12
E		$\frac{5}{16}$ "*60mm BOLT	4





Diagram 1






Diagram 2

1. Place the top upside down on a soft surface;
2. Attach the pedestal to the top, align holes on the pedestal and the top ,insert bolt (B),lock washer (C) and flat washer (D) into each hole;
3. Secure the bolt (B) in clockwise direction with allen wrench (A) (see diagram 1);
4. Attach the other pedestal in the same way as step 2 and step 3;
5. Place the rail onto two pedestals;
6. Insert 2pcs bolts (E) with lock washers (C) and flat washers (D) into holes on rail of each side and corresponding holes in pedestal;
7. Secure the bolts (E) with allen wrench (A);
8. Turn the table upright.



Instruction for the leaves:

1. There is a latch on the bottom of the top, turn on the latch as the diagram 3 shows.
2. Pull out the table top as the arrow direction shown in diagram 4.
3. Place the leaves on it and push them together.
4. Turn off the latch. (see diagram 3)

Cleaning Instruction: Clean finished parts with a damp cloth using a mild dishwashing liquid and water solution. Polish the finish with soft cloth and an industry recognized furniture polish.

ASSEMBLY INSTRUCTION

Item#: 5070-75001 Round Dining Table Base(C)

Item#: 5070-75002 Round Dining Table Top(C)

Item#: 5070-75012 Round Urn Table Top

*** Please make sure you have all parts indicated below prior to assembly.
This unit is heavy and can best be assembled with the help of two or more people.

NO.	HARDWARE LIST		Q'TY
A		ALLEN WRENCH	1
B		$\frac{5}{16}$ "*35MM BOLT	4
C		$\frac{5}{16}$ " LOCK WASHER	8
D		$\frac{5}{16}$ " FLAT WAHSER	8
E		$\frac{5}{16}$ "*40MM BOLT	4




DIAGRAM 1




DIAGRAM 2

Assembly steps:

1. Place the base upright, use 4 bolts (E), 4 lock washers (C) and 4 flat washers(D) to attach the mounting bridge to the base, and tighten all bolts securely with allen wrench (A) (See diagram 1).
2. Put the top on the base, align the holes on the top with the dowels (F) on the mounting bridge, use 4 bolts (B), 4 lock washers (C) and 4 flat washers(D), and tighten all bolts securely with allen wrench (A) (See diagram 2).

Cleaning Instruction: Clean finished parts with a mild dishwashing liquid and water solution on a damp cloth.
Polish the finish with soft cloth and an industry recognized furniture polish.

ASSEMBLY INSTRUCTION

Item#: 5070-75411 Wood Back Side Chair

** Please make sure you have all parts indicated below prior to assembly.

HARDWARE LIST			
No	Item	Description	Q'ty
A		$\frac{5}{16}$ " FLAT WASHER	9
B		$\frac{5}{16}$ " LOCK WASHER	9
C		$\frac{5}{16}$ " X70MM BOLT	4
D		ALLEN WRENCH	1
E		$\frac{5}{16}$ " X50MM BOLT	5
F		SCREW	4





DIAGRAM 1




DIAGRAM 2




DIAGRAM 3




DIAGRAM 4

Assembly Steps:

There are two K/D chairs in one box. Please follow numbers on one chair and letters on the other chair during assembly.


1. Place back frame (G) on a clean surface.
2. Tighten the rear corner blocks of seat frame (I) to back legs of frame (G) using bolts (C), lock washers (B), flat washers(A). Also tighten the back legs of frame(G) to the seat frame(I) by using bolt(E), lock washer(B) and flat washer(A). (See diagram 1&3)
3. Insert stretcher (H) to holes at the back legs of frame (G). (See diagram 2)
4. Assemble front legs with front corner blocks of seat frame (I) using bolts (E), lock washers (B), flat washers (A). Tighten all the bolts by hand. (See diagram 3)
5. Attach front legs to stretcher (H) by using Philips head driver and screws (F). (See diagram 4)
6. After all bolts are attached and hand tightened, turn the chair upright.
7. Level the chair following the "chair leveling instruction" as below.
8. Make sure the chair is level and then tighten all bolts completely by using the allen wrench(D).

PLEASE READ THESE INSTRUCTIONS PRIOR TO ASSEMBLING THE CHAIRS CHAIR LEVELING INSTRUCTION SUPPLEMENT

Chair leveling procedures:

To make the assembly process easy and efficient, please read the entire instruction sheet prior to assembling of the chair. Make sure all hardware listed is included. To properly assemble the chair, none of the bolts should be fully tightened until all components are attached to the chair. This will allow an opportunity to level the chair and prevent any unnecessary "rocking".

1. Place the loosely assembled chair on a hard flat surface.
2. Apply gentle downward pressure on the seat. This step eliminates rocking and ensures the chair to be level.
3. Once the chair is level, tighten all bolts and nuts.



Note:

Most floors have slight irregularities that can affect chair leveling. If your chair is uneven when placed in its desired location, perform the following steps:

1. Loosen front legs to finger tight.
2. Extend both front legs upward to their fullest length.
3. Gently push downward on the front edge of the seat until all four legs rest on the floor.
4. Re-tighten all bolts and nuts.

Cleaning Instruction: Clean finished parts with a damp cloth using a mild dishwashing liquid and water solution. Polish the finish with soft cloth and an industry recognized furniture polish.