


ITEM: 6952-75203T-80 Round Dining Table Top
6952-75203B-85 Round Dining Table Barrel Base

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process.

HARDWARE PACK				
NO.	DRAWING	DESCRIPTION	SIZE	Q'TY
A		Allen Wrench	73*29*5mm	1 PC
B		Bolt	5/16*35mm	12 PCS
C		Lock Washer	5/6"	12 PCS
D		Flat Washer	5/6"	12 PCS

PART LIST			
NO.	DRAWING	DESCRIPTION	Q'TY
①		Table Top	1 PC
②		Bottom Base	1 PC
③		Mounting Plate	1 PC



STEP 1:


Remove the mounting plate (3) from the table top (1).

ITEM: 6952-75203T-80 Round Dining Table Top

6952-75203B-85 Round Dining Table Barrel Base

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process.

**STEP 2:**


Attach the mounting plate (3) to the bottom base (2).

ITEM: 6952-75203T-80 Round Dining Table Top

6952-75203B-85 Round Dining Table Barrel Base


Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process.




STEP 3:

Attach the bottom base (2) to the table top (1).



STEP 4:

Adjust leveler if needed to level table on uneven floor.



Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.


Read all instruction and study the drawing carefully before starting the assembly process.

HARDWARE PACK				
NO.	DRAWING	DESCRIPTION	SIZE	Q'TY
A		Allen Wrench	73*29*5MM	1 PC
B		Bolt	5/16*90mm	4 PCS
C		Bolt	5/16*55mm	6 PCS
D		Lock Washer	5/6"	10 PCS
E		Flat Washer	5/16*22mm	10 PCS

PART LIST			
NO.	DRAWING	DESCRIPTION	Q'TY
①		Base Frame	2 PCS
②		Top Frame	1 PC
③		Stretchers	1 PC

STEP 1:

Insert bolts (B) to base frame (1) and tighten to top frame (2) by allen wrench (A). Do not fully tighten at this step.



STEP 3:

Insert bolts (C) to stretcher (3) and tighten to base frame (1) by allen wrench (A).


STEP 2:

Insert bolts (C) to top frame (2) and tighten to base frame (1) by allen wrench (A).


Do not fully tighten at this step.

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process.



Adjust leveler if needed to
level table on uneven floor.



ASSEMBLY INSTRUCTION


ITEM: 6952-75217B-80 Rectangle Dining Table Base
6952-75217T-80 Rectangle Dining Table Top

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process.


HARDWARE PACK				
NO.	DRAWING	DESCRIPTION	SIZE	Q'TY
A		Allen Wrench	108*76*5MM	1 PC
B		Bolt	5/16*100mm	4 PCS
C		Bolt	5/16*50mm	12 PCS
D		Lock Washer	5/6"	16 PCS
E		Flat Washer	5/16*22mm	16 PCS

PART LIST			
NO.	DRAWING	DESCRIPTION	Q'TY
①		Table Top	1 PC
②		Base	2 PCS
③		Stretcher	2 PCS
④		Leaf	2 PCS



STEP 1:
Insert bolts (B) to base (2)
and tighten to table top(1)
by allen wrench (A).

STEP 2:
Insert bolts (C) to base (2)
and tighten to table top(1)
by allen wrench (A).




ASSEMBLY INSTRUCTION

ITEM: 6952-75217B-80 Rectangle Dining Table Base
6952-75217T-80 Rectangle Dining Table Top


Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process.



STEP 3:


Attach stretcher (3) to table top (1).



ITEM: 6952-75217B-80 Rectangle Dining Table Base
6952-75217T-80 Rectangle Dining Table Top


Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process.



STEP 4:

Pull out both ends of table top (1) as the arrow direction, place the leaf (4) between and push them together, lock the latches.




Note: Take opposite actions to remove table leaf.

ASSEMBLY INSTRUCTION


ITEM: 6952-75450-80 Counter Chair

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process.



Adjust leveler if needed to
level chair on uneven floor.



Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.



Read all instruction and study the drawing carefully before starting the assembly process.

HARDWARE PACK

NO.	DRAWING	DESCRIPTION	SIZE	Q'TY
A		Anti - Tip Kit		1 PC



Tipping Restraint

Anti-tip kit is included for use.
We recommend installing for
safety reason.



The adjustable shelf is
screwed in place to
avoid damage during
transit.


To adjust the shelf
height, remove screws
then place shelf pins in
the desired level.




Adjust leveler if needed to level
buffet on uneven floor.



Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process.

HARDWARE PACK				
NO.	DRAWING	DESCRIPTION	SIZE	Q'TY
A		Allen Wrench	69*27.2*4mm	1 PC
B		Bolt	1/4*25mm	2 PCS
C		Lock Washer	1/4(6mm)	2 PCS
D		Flat Washer	1/4*16mm	2 PCS
E		Hanger	75*30*38mm	2 PCS
F		Screw	8*1 1/4	2 PCS
G		Plastic Anchor		2 PCS
H		Anti-Tip Kit		1 PC
I		Open Wrench	8mm/70mm	1 PC



STEP 1:
Mount the hanger (E) to top of the cabinet, then attach the cabinet to a wall.




STEP 2:
The adjustable shelves are screwed in place to avoid damage during transit. To adjust the shelf height, remove screws then place shelf pins in the desired level.

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.


Read all instruction and study the drawing carefully before starting the assembly process.

Anti-tip kit is included for use.
We recommend installing for
safety reason.



Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process.



- A—— male connector (of the power switch)
- B—— female connector (of the power switch)
- C—— male connector (of the puck light)
- D—— female connector (of the puck light)
- E—— male connector (of the power wire)
- F—— female connector (of the power wire)







Diagram 1



#1



#2



#3

Diagram 2

Assembly Steps

1. When each piece of cabinet is used alone, attach male connector of the power switch (A) to a wall plug. (See Diagram 1)
2. Touch dimmer is at the inside of right post.
3. If you want to bunch two or more cabinets together, place them all side by side in a desired location.
4. Leave male connector of the puck light (C) and female connector of power switch (B) for the first cabinet (#1) as it is. Keep male connector of the puck light (C) and female connector of power switch (B) off for the rest cabinets (#2, #3, and so on). (See Diagram 2)

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process.




Diagram 3

Assembly Steps

5. Connect female connector of the puck light (D) (#1 cabinet) with male connector of power wire (E), then have female connector of power wire (F) connected to male connector of puck light (C) (the #2 cabinet). (See Diagram 3)
6. Repeat step 5 for the 3rd cabinet and the rest ones when more than two are bunched together till each one is connected.
7. Plug in male connector of power switch (A) (#1 cabinet).
8. Touch the dimmer of the #1 cabinet, all puck lights connecting together will be on at the same time.

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process.

Hinge Replace Instruction:

When the door hinge is damaged, use the Open Wrench (I) to unscrew the hardware and replace with the new hinge.

