

Assembly Instruction

ITEM N0.:9360BEG-2LRPW/2RRPW (1/2)Power Left Side Reclining Chair for Love Seat/ (2/2)Power Right Side Reclining Chair for Love Seat

Legs & hardware are stored at the bottom of the seat, please take out for

assembly.

Note: Do not use power tools for assembly. Power tools increase the risk of over tightening which lead to splitting or cracking the wood.


Component list


Label	Picture	QTY	Description
А		4 PCS	Metal Leg H 5 1/2″
В	\bigcirc	16 PCS	Metal Washer ¢1/2 "
с		16 PCS	Bolt φ1/2"X1"
D		1 PC	Allen Key 21/4"X1"
E		2 PCS	Back Rest
F		1 PC	LSF Seat
G		1 PC	RSF Seat
		Page 1 of 4	


Step 1

Adaptor set is pre-connected and located under the right side seat,

please take out the plug and wire for use.







Care Instruction for Top Grain Leather Furniture:

In order to maintain the original appearance of your Top Grain Leather furniture, please follow below simple care procedures:

- Avoid exposing furniture directly to sunlight or heating and air conditioning outlets.Sunlight and or exposure to heating and air conditioning outlets will fade/damage top grain leather.
- Vacuum or wipe with a soft cloth to remove dust.



For item use on wooden floor,hard surfaces or carpets,it is recommended to install protective pads under all legs and supports to avoid/prevent from damages/scratches and discoloration.

Warning

Do not allow electrical cord to be pinched between moving parts or between the frame and the floor.Do not place cord under carpet or in location where it could become worn.