ASSEMBLY INSTRUCTIONS

ITEM: 72212

Important note:

- Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid scratching the parts.
- Kindly follow the assembly instructions step by step.
- Do not tighten all screws and bolts until the chair is fully assembled.

NO	COMPONENT	QTY
1	Chair Back	1
2	Seat Frame	1
3	Left Front Leg	1
4	Right Front Leg	1

NO	HARDWARE		QTY
Α	BOLT (LONG)	0	4
В	BOLT (MEDIUM)	0	4
С	BOLT (SHORT)	©	3
D	SPRING WASHER	6	11
Е	FLAT WASHER	0	11
F	ALLEN KEY		1







