HOOKER® FURNISHINGS ASSEMBLY INSTRUCTION

Item: 6072-75200-85 Rect Dining Table w/one 18in leaf

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.
Read all instruction and study the drawing carefully before starting the assembly process.

PARST LIST

1	TABLE TOP	1 SET
2	TABLE LEAF	1 Pcs
3	LEGS	4 Pcs

HARDWARE LIST				
NO.	DESCRIPTION	SIZE	DRAWING	Q'TY
A	NUT	Ø5/16"		8PCS
B	LOCK WASHER	Ø5/16"		8PCS
C	FLAT WASHER	Ø5/16"*19MM		8PCS
D	OPEN WRENCH	13mm		1PC



STEP 1







STEP 2



STEP 1 : Place the top panel on smooth carpet, and then fix legs with top panel with flat washers(C)、lock washers(B) and nut (A). Tighten all bolts with the hex wrench (D) .

STEP 2 : Stand the assembled table, and then release the locks under the table top and pull the tops apart .
Place extension leaf in the middle and close tops.Tighten the locks .

HOOKER® FURNISHINGS

ASSEMBLY INSTRUCTION

Item: 6072-75900-85 Dining Credenza

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.
Read all instruction and study the drawing carefully before starting the assembly process.

HARDWARE LIST				
NO	DRAWING	DESCRIPTION	SIZE	Qty
A		TIPPING RESTRAINT		1pc
B		Shelf pin		8pcs
C		Screw	Ø6*5/8"	8pcs

Tipping restraint here.







HOOKER® FURNISHINGS

ASSEMBLY INSTRUCTION

Item: 6072-75906-85 Display Cabinet

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.
Read all instruction and study the drawing carefully before starting the assembly process.

HARDWARE LIST				
NO	DRAWING	DESCRIPTION	SIZE	Qty
A		Plastic Insert		2pcs
B		Screw	Ø8*1-1/4"	2pcs
C		Allen Wrench	4 mm	1pc

STEP 1. Take off metal bracket by loosening bolt pre-secured on top , and then separately secure Mending plate to wall with screw (not provided) and top with bolt .