


# Assembly Instructions

CM-BK928FF



## ASSEMBLY RATING

The Assembly Rating is a 5-point system that shows the degree of effort needed in assembling a specific product (with 1 being easy and 5 being difficult). For some products, two persons are recommended.



EASY



DIFFICULT

## Tools Required For Assembly:

Allen Wrench




2 PERSONS RECOMMENDED

# ASSEMBLY & CARE ADVICE

FOR YOUR FURNITURE TO LAST, CORRECT ASSEMBLY AND PROPER MAINTENANCE ARE NECESSARY. PLEASE FOLLOW THE INFORMATION PROVIDED BELOW TO FULLY ENJOY YOUR FURNITURE.


## BASIC ASSEMBLY TECHNIQUES




When lock or spring washer is used in an assembly, please make sure the lock or spring washer is placed between the larger flat washer and the head of the screw or bolt.




Position each part correctly and insert screws or bolts into their respective holes by hand tighten or using the proper hand tool. Only tighten when step is completed or when instructed to do so.




Use cardboard or carpet area when assembling furniture to prevent scratches. Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.



Some furniture comes with height adjustment knobs underneath each leg. To lower or to raise each leg, you need to turn clockwise or counterclockwise, respectively.




Make sure all parts are properly aligned, then use the appropriate hand tool to completely tighten the bolts or screws. Do not use power tools and do not overtighten.



Save the instructions and store the Allen wrench or any supplied tool for later maintenance. After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.




**FAILURE TO FOLLOW THE GUIDELINES ABOVE MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.**




Before you begin, please read Page 2 of "Assembly and Care Advice".

And remember, do not tighten until each step is completed or instructed.

## Parts List




#1 x 1pc  
Upper End Rail (Left)




#2 x 1pc  
Upper End Rail (Right)




#3 x 4pcs  
Bed Support Tube




#4 x 2pcs  
Lower Bed Rail




#5 x 1pc  
Rear Guardrail




#6 x 1pc  
Front Guardrail




#7 x 1pc  
Rear Connected Bar




#8 x 1pc  
Front Connected Bar




#9 x 4pcs  
Bed Side Frame




#10 x 2pcs  
Upper Middle Frame



#11 x 2pcs  
Lower Middle Frame



#12 x 2pcs  
Middle Connect Bar



#13 x 1pc  
Ladder



#14 x 2pcs  
Support Leg



Before you begin, please read Page 2 of "Assembly and Care Advice".

And remember, do not tighten until each step is completed or instructed.

## Hardware List



#A x 36pcs  
Bolt 1/4" X 1"



#B x 4pcs  
Bolt 1/4" X 1-1/8"



#C x 3pcs  
Bolt 1/4" X 1-3/8"



#D x 16pcs  
Bolt 1/4" X 1-1/2"



#E x 16pcs  
Bolt 1/4" X 3"



#F x 8pcs  
Spacer




#G x 1pc  
Allen Wrench M4




- I. Align the lower bed rail (#4) to the pre-drilled holes along the sides of the bed support tube (#3).
- II. Insert 2 bolts (#D) into the pre-drilled holes on each end and secure using the Allen wrench (#G).  
Repeat process a second time.

#D x 8pcs



- Insert the upper end rail (#1) onto one set of bed support tubes.  
Insert the upper end rail (#2) onto the other pair of bed support tubes.






#C x 3pcs  
#E x 16pcs  
#F x 8pcs

- 2.
- Align the top part of the front guardrail (#6) and the rear guardrail (#5) to the top pre-drilled holes on the upper end rails.
  - Insert a bolt (#C) into each end from within. Secure using the Allen wrench (#G).



- 1.
- Align the front guardrail (#6) and the rear guardrail (#5) to the corners of the upper end rails.
  - Align a spacer (#F) to each end and insert bolts (#E). Secure using the Allen wrench (#G).

- 3.
- Align the rear connect bar (#7) and the front connect bar (#8) to the bottom pre-drilled holes along the sides of the lower bed rails. Make sure they match the upper rail placements.
  - Align a spacer (#F) to each end and insert bolts (#E). Secure using the Allen wrench (#G).



#A x 32pcs

Top Assembly: Align the 2 bed side frames (#9) to the pre-drilled holes on the ends and insert bolts (#A) into each pre-drilled hole. Secure using the Allen wrench (#G). Then align 2 upper middle frames (#10) to the pre-drilled holes along the center and insert bolts (#A) into each hole. Secure using the Allen wrench (#G).




Bottom Assembly:  
Align the 2 bed side frames (#9) to the pre-drilled holes on the ends and insert bolts (#A) into each pre-drilled hole. Secure using the Allen wrench (#G). Then align 2 lower middle frames (#11) to the pre-drilled holes along the center and insert bolts (#A) into each hole. Secure using the Allen wrench (#G).




#B x 4pcs  
#D x 4pcs

Align the middle connect bar (#12) to the center pre-drilled holes located under the bed frames. Then insert 2 bolts (#B) into each along the center. Secure using the Allen wrench (#G). Insert a bolt (#D) into each end and secure using the Allen wrench (#G).



#D x 4pcs



Align the ladder (#13) to the pre-drilled holes along the opening of the front guardrail. Insert a bolt (#D) into each end and secure using the Allen wrench (#G).






Align the top of the support legs (#2) to the bottom of the lower middle frame.  
Insert 2 bolts (#A) into each from the top and secure using the Allen wrench (#G).

#A x 4pcs



Make sure all parts are firmly secured.



**ASSEMBLY IS COMPLETED**